


# SERVICE MANUAL

# BG-3S CHASSIS

<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>	<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>
KV-XF25M30	RM-954	Australia	SCC-U23A-A				
KV-XF25M50	RM-954	Thailand	SCC-U18D-A				
KV-XF25M50	RM-954	Indonesia	SCC-U20L-A				
KV-XF25M63	RM-954	Thailand	SCC-U18C-A				
KV-XF25M65	RM-954	Indonesia	SCC-U20D-A				
KV-XF25M65	RM-954	Indonesia	SCC-U20M-A				
KV-XF25M90	RM-954	ISR	SCC-U19B-A				



TRINITRON® COLOR TV  
**SONY®**


# SERVICE MANUAL

# BG-3S CHASSIS

<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>	<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>
KV-XF25M50	RM-954	India	SCC-U22S-A				
KV-XF25M80	RM-954	India	SCC-U22T-A				



(RM-954)



TRINITRON® COLOR TV  
**SONY®**

## SPECIFICATIONS

		Note
Power requirements	110-240 V AC, 50/60 Hz	
Power consumption (W)	Indicated on the rear of the TV	
Television system	B/G, I, D/K, M	
Color system	PAL, PAL 60, SECAM, NTSC4.43, NTSC3.58	
Channel coverage		
B/G	VHF: E2 to E12 / UHF: E21 to E69 / CATV: S01 to S03, S1 to S41	
I	UHF: B21 to B68 / CATV: S01 to S03, S1 to S41	
D/K	VHF: C1 to C12, R1 to R12 / UHF: C13 to C57, R21 to R60 CATV: Z1 to Z39, S01 to S03, S1 to S41	
M	VHF: A2 to A13 / UHF: A14 to A79 / CATV: A-8 to A-2, A to W+4, W+6 to W+84	
ㄗ (Antenna)	75-ohm external terminal	
Audio output	6W + 6W	
Number of terminal		
📺 (Video)	Input: 3   Output: 1                          Phono jacks; 1 V <sub>P-P</sub> , 75 ohms	
🎵 (Audio)	Input: 3   Output: 1                          Phono jacks; 500 mVRms	
📺➡️ (S Video)	Input: 2    Y : 1 V <sub>p-p</sub> , 75 ohms, unbalanced, sync negative C :0.286 V <sub>p-p</sub> , 75 ohms	
🎧 (Headphone)	Output: 1    Minijack	
Picture tube	25 inch	
Tube size (cm)	64    Measured diagonally	
Screen size (cm)	60    Measured diagonally	
Dimension (w/h/d, mm)	722 × 515 × 512	
Mass (kg)	39	

Design and specifications are subject to change without notice.

### CAUTION

**SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.**

## SAFETY-RELATED COMPONENT WARNING!!

**COMPONENTS IDENTIFIED BY SHADING AND MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.**

## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
	<b>SELF DIAGNOSIS FUNCTION</b> .....	4			
<b>1. GENERAL</b> .....		8	<b>5. DIAGRAMS</b>		
<b>2. DISASSEMBLY</b>			5-1. Block Diagram .....	41	
2-1. Rear Cover Removal .....	22		5-2. Frame Schematic Diagram .....	45	
2-2. Speaker Bracket Removal .....	22		5-3. Circuit Boards Location .....	49	
2-3. Chassis Assy Removal .....	22		5-4. Schematic Diagrams and Printed Wiring Boards ...	50	
2-4. F Bracket Removal .....	22		(1) Schematic Diagram of A (1/2) Board .....	52	
2-5. Service Position .....	23		(2) Schematic Diagram of A (2/2) Board .....	55	
2-6. Replacement of Parts .....	23		(3) Schematic Diagram of B2 Board .....	60	
2-6-1. Replacement of Control Button .....	23		(4) Schematic Diagrams of H3 and VM1 Boards .....	61	
2-6-2. Replacement of Light Guide .....	23		(5) Schematic Diagram of B3 Board .....	95	
2-7. Terminal Bracket Removal .....	23		(6) Schematic Diagram of F Board .....	71	
2-8. H3 Board Removal .....	24		(7) Schematic Diagram of C Board .....	73	
2-9. A and B3 Boards Removal .....	24		5-5. Semiconductors .....	76	
2-10. Picture Tube Removal .....	24				
<b>3. SET-UP ADJUSTMENTS</b>			<b>6. EXPLODED VIEWS</b>		
3-1. Beam Landing .....	26		6-1. Speaker Bracket .....	79	
3-2. Convergence .....	27		6-2. Chassis .....	80	
3-3. Focus Adjustment .....	29		6-3. Picture Tube .....	81	
3-4. G2 (Screen) and White Balance Adjustments .....	30				
<b>4. CIRCUIT ADJUSTMENT</b>			<b>7. ELECTRICAL PARTS LIST</b> .....	82	
4-1. Adjustments with Commander .....	31				
4-2. Adjustment Method .....	32				
4-3. Picture Quality Adjustments .....	37				
4-4. A Board Adjustment After IC003 (Memory) Replacement .....	37				
4-5. Picture Distortion Adjustment .....	38				

## SELF DIAGNOSTIC FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the STANDBY/TIMER lamp will automatically begin to flash.

The number of times the lamp flashes translates to a probable source of the problem. A definition of the STANDBY/TIMER lamp flash indicators is listed in the instruction manual for the user's knowledge and reference. If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

### 1. DIAGNOSTIC TEST INDICATORS

When an errors occurs, the STANDBY/TIMER lamp will flash a set number of times to indicate the possible cause of the problem. If there is more than one error, the lamp will identify the first of the problem areas.

Result for all of the following diagnostic items are displayed on screen. No error has occurred if the screen displays a "0".



Diagnostic Item Description	No. of times STANDBY/TIMER lamp flashes	Self-diagnostic display/Diagnostic result	Probable Cause Location	Detected Symptoms
• Power does not turn on	Does not light	—	<ul style="list-style-type: none"> <li>• Power cord is not plugged in.</li> <li>• Fuse is burned out F4601 (F)</li> </ul>	<ul style="list-style-type: none"> <li>• Power does not come on.</li> <li>• No power is supplied to the TV.</li> <li>• AC power supply is faulty.</li> </ul>
<ul style="list-style-type: none"> <li>• +B overcurrent (OCP) or overvoltage (OVP)</li> <li>• Vertical deflection stopped</li> <li>• Horizontal deflection overdrive</li> </ul>	2 times	002:000 or 002:001~255 003:001~255 004:001~255 at the same time	<ul style="list-style-type: none"> <li>• H.OUT Q511 is shorted. (A board)</li> <li>• IC701 is shorted. (C board)</li> <li>• -13V is not supplied. (A board)</li> <li>• IC 503 faulty (A board)</li> </ul>	<ul style="list-style-type: none"> <li>• Power does not come on.</li> <li>• Load on power line is shorted.</li> <li>• Has entered standby state after horizontal raster.</li> <li>• Vertical deflection pulse is stopped.</li> <li>• Power line is shorted or power supply is stopped.</li> </ul>
• White balance failure (no PICTURE)	5 times	005:000 or 005:001~225	<ul style="list-style-type: none"> <li>• G2 is improperly adjusted. (Note 2)</li> <li>• CRT problem.</li> <li>• Video OUT IC701 is faulty. (C board)</li> <li>• IC301 is faulty. (A board)</li> <li>• No connection A board to C board.</li> </ul>	<ul style="list-style-type: none"> <li>• No raster is generated.</li> <li>• CRT cathode current detection reference pulse output is small.</li> </ul>
• Micro reset	—	101:00 or 101:001~225	<ul style="list-style-type: none"> <li>• Discharge CRT (C Board)</li> <li>• Static discharge</li> <li>• External noise</li> </ul>	<ul style="list-style-type: none"> <li>• Power is shut down shortly, after this return back to normal.</li> <li>• Detect Micro latch up.</li> </ul>

Note 1: If a + B overcurrent is detected, stoppage of the vertical deflection is detected simultaneously.

The symptom that is diagnosed first by the microcontroller is displayed on the screen.

Note 2: Refer to screen (G2) Adjustment in section 3-4 of this manual.

## 2. DISPLAY OF STANDBY/TIMER LIGHT FLASH COUNT



<u>Diagnostic Item</u>	<u>Flash Count*</u>
+B overcurrent/overvoltage Vertical deflection stopped	2 times
White balance failure	5 times

\* One flash count is not used for self-diagnostic.

## 3. STOPPING THE STANDBY/TIMER FLASH

Turn off the power switch on the TV main unit or unplug the power cord from the outlet to stop the STANDBY/TIMER lamp from flashing.

#### 4. SELF-DIAGNOSTIC SCREEN DISPLAY

For errors with symptoms such as “power sometimes shuts off” or “screen sometimes goes out” that cannot be confirmed, it is possible to bring up past occurrences of failure for confirmation on the screen:

##### [To Bring Up Screen Test]

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

Screen display → channel [5] → Sound volume [-] → Power ON



Note that this differs from entering the service mode (mode volume [+]).

##### Self-Diagnosis screen display

SELF DIAGNOSTIC	
002 : 000	←
003 : 000	
004 : 000	
005 : 001	←
101 : 000	

Numeral "0" means that no fault has been detected.

Numeral "1" means a fault has been detected.

#### 5. HANDLING OF SELF-DIAGNOSTIC SCREEN DISPLAY

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen during repairs. When you have completed the repairs, clear the result display to “0”.

Unless the result display is cleared to “0”, the self-diagnostic function will not be able to detect subsequent faults after completion of the repairs.

##### [Clearing the result display]


To clear the result display to “0”, press buttons on the remote commander sequentially as shown below when the diagnostic screen is being displayed.

Channel [8] → 0

##### [Quitting Self-diagnostic screen]

To quit the entire self-diagnostic screen, turn off the power switch on the remote commander or the main unit.

## 6. SELF-DIAGNOSTIC CIRCUIT



### **+B overcurrent (OCP)**

Occurs when an overcurrent on the +B(135) line is detected by Q604. If Q604 go to ON and the voltage to pin 18 of IC301 should go down when V.SYNC is more than seven verticals in a period, the unit will automatically turn off.

### **Vertical deflection stopped**

Occurs when an absence of the vertical deflection pulse is detected by Q509 and IC001 shut down the power supply.

### **Vertical deflection overcurrent**

Occurs when an overcurrent on V drive line is detected by Q507. Power supply will be shut down when detect this by IC001.

### **White balance failure**

If the RGB levels\* do not balance or become low level within 5 seconds, this error will be detected by IC301. TV will stay on, but there will be no picture.

\* (Refers to the RGB levels of the AKB detection Ref pulse that detects IK.)




The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

## SECTION 1 GENERAL

### WARNING

- Dangerously high voltages are present inside the TV.
- Operate the TV only between 110 – 240 V AC.



2


### Using Your New TV

## Getting Started

### Step 1

#### Connect the antenna

If you wish to connect a VCR, see the "Connecting a VCR" diagram below.




#### CAUTION

Do not connect the power cord until you have completed making all other connections; otherwise a minimum leakage current might flow through the antenna and other terminals to ground.

#### Connecting a VCR

To watch the video, see page 9.




4 Using Your New TV

#### Notes

- If you connect a monaural VCR, connect the yellow plug to (the yellow jack) and the black plug to L (MONO) (the white jack).
- If you connect a VCR to the (antenna) terminal, preset the signal output from the VCR to the program number 0 on the TV.
- If both (S video input) and (video input) at the rear of your TV are input at the same time, the (S video input) is automatically selected. To view (video input), disconnect the S video cable.
- When no signal is input to the connected video equipment, the TV screen becomes blue.

## Step 2

### Insert the batteries into the remote




#### Note

- Do not use old batteries nor use different types of batteries together.

## Step 3

### Preset the channels automatically

Front of TV



#### Tips


- If you want to stop the automatic channel presetting, press MENU twice.
- If your TV has preset an unwanted channel or cannot preset a particular channel, then preset your TV manually (see page 21 and 22).

#### Note

- During automatic channel presetting, your TV screen will indicate "B/G", "I", "D/K" or "M" for the TV system (TV SYS).

Now You Are Ready. . .

To watch your TV, see page 8.



Using Your New TV | 5


## Connecting optional components

You can connect optional audio/video components, such as a VCR, multi disc player, camcorder, video game or stereo system.

To watch the picture of the connected equipment, see page 9.

### Connecting a camcorder/video game equipment using the (video input) jacks

Front of TV




#### Notes

- You can also connect video equipment to the (video input) jacks at the rear of your TV.
- If both (S video input) and (video input) at the front of your TV are input at the same time, the (S video input) is automatically selected. To view (video input), disconnect the S video cable.

### Connecting audio/video equipment using the (monitor output) jacks

Antenna cable (not supplied)



#### Note

- When connecting a monaural VCR, connect the yellow plug to (the yellow jack) and the black plug to L (MONO) (the white jack).

6 | Using Your New TV


## Securing the TV

To prevent the TV from falling, secure the TV using one of the following methods:

**A** With the supplied screws, attach the band to the TV stand and to the rear of the TV using the provided hole.

or


**B** Put the cord or chain through the clamps to secure the TV against a wall or pillar.



Using Your New TV

## Watching the TV

This section explains functions used while watching TV. Most operations can be done using the remote.




**1** Press ① to turn on the TV.

When the TV is in the standby mode (the ① indicator on the TV is lit red), press ① on the remote or PROGR +/- on the TV.



**2** Press PROGR +/- or number buttons to select the TV program.

For double digit numbers, press +/-, then the number (e.g., for 25, press +/-, then 2 and 5).



**3** Press +/- to adjust the volume.



## Additional tasks

To	Do this
Turn off temporarily	Press . The  indicator on the TV lights up red.
Turn off completely	Press  on the TV.
Mute the sound	Press .
Watch the video input (VCR, camcorder, etc.)	Press  to select "VIDEO 1", "VIDEO 2" and "VIDEO 3". To return to the TV program, press .
Jump back to the previous channel	Press JUMP.
Display the on-screen information*	Press .

\* The picture, sound, and either the program number or video mode are displayed. The on-screen display for the picture and sound information disappears after about 3 seconds.

## Changing the menu language

You can change the menu language as well as the on-screen language.

For details on how to use the menu, see "How to use the menu" on page 15.

- Press MENU. →
- Press + or - to select the SET UP icon (), then press ENTER. → →
- Make sure "LANGUAGE/ اللغة" is selected, then press ENTER. →
- Press + or - to select "عربي", then press ENTER. → →

To return to the normal screen


Press MENU.

Using Your New TV

## Watching the TV (continued)

### Setting the Wake Up timer

- Press until the desired period of time appears.  
The Wake Up timer starts immediately after you have set it.



- Select the TV program or video mode you want to display when you wake up.
- Press or set the Sleep timer if you want the TV to turn off automatically.  
The indicator on the TV lights up orange.

### To cancel the Wake Up timer

Press until "WAKE UP TIMER: OFF" appears or turn off the TV's main power.


#### Note

- If no buttons or controls are pressed for more than two hours after the TV is turned on using the Wake Up timer, the TV automatically goes into the standby mode. To continue watching the TV, press any button or control on the TV or the remote.

### Setting the Sleep timer

Press until the desired period of time appears.

The Sleep timer starts immediately after you have set it.



### To cancel the Sleep timer


Press until "SLEEP TIMER: OFF" appears or turn the TV off.

continued

## Advanced Operations


### Selecting the picture and sound modes

You can select picture and sound modes and adjust the setting to your preference in PERSONAL option.



#### Selecting the picture mode


Press PIC MODE repeatedly until you get the desired picture mode.



Select	To
DYNAMIC	receive high contrast pictures.
STANDARD	receive normal contrast pictures.
SOFT	receive mild pictures.
PERSONAL	receive the last adjusted picture setting from the ADJUST option in the A/V CONTROL menu (see page 17).

#### Selecting the sound mode

Press SOUND MODE repeatedly until you get the desired sound mode.




Select	To
DYNAMIC	listen to dynamic and clear sound that emphasizes the low and high tones.
DRAMA	listen to sound that emphasizes voice and high tones.
SOFT	receive soft sound.
PERSONAL	receive the last adjusted sound setting from the ADJUST option in the A/V CONTROL menu (see page 17).

#### Tip


- You can also set the picture and sound modes using the menu (see "Changing the A/V CONTROL setting" on page 16).

### Viewing your favorite channels


You can display and select six of your favorite channels directly from your TV screen.



#### 1 Press FAVORITE.



#### 2 Press the number button from 1 to 6 to select the desired channel.




#### Tip


- To program your favorite channels, see "Programming your favorite channels" on page 18.

# Listening with surround sound

The surround feature enables you to enjoy the sound effects of a concert hall or movie theater.



Press SURROUND repeatedly until you receive the desired surround sound.



Select	To
HIGH	listen to sound that spreads out over a large area, giving the feeling of being at a concert hall.
LOW	listen to the sound that gives the feeling of being at a live concert.
OFF	turn off the surround sound.


The surround of your TV is categorized as TruSurround.

**TruSurround**™ is a trademark of SRS Labs, Inc. SRS and the SRS symbol are registered trademarks of SRS Labs, Inc. in the United States and selected foreign countries. SRS and TruSurround are incorporated under license from SRS Labs, Inc. and are protected under United States Patent Nos. 4,748,669 and 4,841,572 with numerous additional issued and pending foreign patents.

## Adjusting Your Setup (MENU)

### Introducing the menu system

The MENU button lets you open a menu and change the settings of your TV. Here's an overview of the menu system.




Level 1	Level 2	Level 3/Function
A/V CONTROL 	PICTURE MODE	Select the picture mode. DYNAMIC → STANDARD → SOFT → PERSONAL → ADJUST
	ADJUST	Adjust the PERSONAL option. PICTURE → COLOR → BRIGHT → HUE → SHARP
	SOUND MODE	Select the sound mode. DYNAMIC → DRAMA → SOFT → PERSONAL → ADJUST
	ADJUST	Adjust the PERSONAL option. BASS → TREBLE → BALANCE → BBE *
SET UP 	SURROUND	Select the surround mode. HIGH → LOW → OFF
	LANGUAGE/ اللغة	Change the menu language. ENGLISH - عربي (Arabic)
	CHILD LOCK	Lock the channel independently.
	PIC ROTATION	Adjust the picture position.
	FAVORITE CH	Program favorite channels.
CH PRESET 	INTELLIGENT VOL	Adjust volume automatically.
	AUTO PROGRAM	Preset channels automatically.
	MANUAL PROGRAM	Preset channels manually.
	SKIP	Skip unwanted or unused program positions.
	TV SYS	Select the TV system. B/G → I → D/K → M
	COL SYS	Select the color system. AUTO → PAL → SECAM → NTSC3.58 → NTSC4.43

\* The BBE is manufactured by Sony Corporation under license from BBE Sound, Inc. It is covered by U.S. Patent No. 4,638,258 and No. 4,482,866. The word "BBE" and the BBE symbol are the trademarks of BBE Sound, Inc.

## How to use the menu

You can use the buttons on the remote and on the TV as well to display the menu and adjust the settings.



- 1 Press MENU to display the menu.



- 2 Press + or - to select the desired item.



- 3 Press ENTER to confirm your option and go to the next menu level.



### Other menu operations


To	Press
Adjust the setting value	+/-
Return to the previous menu level*	ENTER
Cancel the menu	MENU

\* To return from Menu Level 2 to Level 1, press + or - to select the return icon (↩), then press ENTER.

#### Tips


- If more than 60 seconds elapse between entries, the menu screen disappears.
- You can also use the buttons on the TV for menu operations. ◀ +/- work as + / - on the remote and ▶ works as ENTER on the remote.

#### Front of TV



## Changing the A/V CONTROL setting

The A/V CONTROL menu allows you to change the picture and sound settings.




- 1 Press MENU.


- 2 Make sure the A/V CONTROL icon (A/V) is selected, then press ENTER.



- 3 Press + or - to select either PICTURE MODE, SOUND MODE or SURROUND, then press ENTER.



- 4 Press + or - to select the desired option, then press ENTER.



For	Select
PICTURE MODE	either DYNAMIC, STANDARD, SOFT, PERSONAL*, or ADJUST.
SOUND MODE	either DYNAMIC, DRAMA, SOFT, PERSONAL*, or ADJUST.
SURROUND	either HIGH, LOW, or OFF.

\* When the PERSONAL mode is selected, the last adjusted picture and sound settings from the ADJUST option are received (see next page).


#### Tip

- For details on the options under "PICTURE MODE", "SOUND MODE" and "SURROUND", see page 11 and 13 respectively.

### To return to the normal screen

Press MENU.

## Adjusting the ADJUST options under PICTURE MODE

- Press + or - to select the desired item (e.g., COLOR), then press ENTER. 


- Adjust the value according to the following table, then press ENTER.

For	Press - to	Press + to
PICTURE	decrease picture contrast	increase picture contrast
COLOR	decrease color intensity	increase color intensity
BRIGHT	darken the picture	brighten the picture
HUE*	increase red picture tones	increase green picture tones
SHARP	soften the picture	sharpen the picture

\* You can adjust HUE for the NTSC color system only.

- Repeat the above steps to adjust other items.  
The adjusted settings will be received when you select PERSONAL.

## Adjusting the ADJUST options under SOUND MODE

- Press + or - to select the desired item (e.g., BALANCE), then press ENTER. 

- Adjust the value according to the following table, then press ENTER.

For	Press - to	Press + to
BASS	decrease the bass	increase the bass
TREBLE	decrease the treble	increase the treble
BALANCE	increase the left speaker's volume	increase the right speaker's volume
BBE	select "HIGH" for higher enhancement of sound clarity; select "LOW" for lower enhancement of sound clarity; select "OFF" to turn off the BBE sound	


- Repeat the above steps to adjust other items.  
The adjusted settings will be received when you select PERSONAL.

### Tip

- For details on the menu system and how to use the menu, refer to "Introducing the menu system" on page 14 and "How to use the menu" on page 15.




## Changing the SET UP setting

The SET UP menu allows you to change the menu language, lock channels, adjust the picture position, program your favorite channels and adjust volume automatically.




## Programming your favorite channels

The FAVORITE CH feature enables you to program up to six channels for direct selection.

- Press MENU.
- Press + or - to select the SET UP icon (⏏), then press ENTER. 
- Press + or - to select FAVORITE CH, then press ENTER twice. 
- Press + or -, or number buttons to program the desired channel (e.g., PR03), then press ENTER. 

or


- To continue programming other favorite channels, press + or - and then press ENTER. After that, repeat step 4.





## To return to the normal screen

Press MENU.



## Using the CHILD LOCK feature

You can prevent your children from watching certain channels by using the CHILD LOCK feature.

- 1 Press MENU.
- 2 Press + or – to select the SET UP icon (⚙️), then press ENTER.
 
- 3 Press + or – to select CHILD LOCK, then press ENTER.
 
- 4 Press + or –, or number buttons to select the desired channel, then press ENTER.
 
- 5 Press + or – to select ON, then press ENTER.
 

The lock symbol (Ⓐ) appears on the screen.  
To unlock the channel, select OFF.
- 6 To continue locking other channels, press ENTER and then repeat step 4 to 5.

### To return to the normal screen

Press MENU.



#### Note


- If you preset a locked channel, that particular channel will be unlocked automatically (see page 21).

continued

## Changing the SET UP setting (continued)

### Changing other SET UP menu options

- 1 Press MENU.
- 2 Press + or – to select the SET UP icon (⚙️), then press ENTER.
 
- 3 Press + or – to select the desired option (e.g., INTELLIGENT VOL), then press ENTER.
 

Select	To
LANGUAGE	Change the menu language (see “Changing the menu language” on page 9).
CHILD LOCK	Prevent children from watching certain channels (see “Using the CHILD LOCK feature” on page 19).
PIC ROTATION	Adjust the picture position when it is not aligned to the TV screen. Press + or – to adjust the picture position, then press ENTER. 
FAVORITE CH	Program channels for direct selection (see “Programming your favorite channels” on page 18).
INTELLIGENT VOL	Adjust the volume of all TV programs automatically. Press + or – to select “ON”, then press ENTER. To turn off the “INTELLIGENT VOL” function, select “OFF”, then press ENTER.

### To return to the normal screen


Press MENU.

#### Tip

- For details on the menu system and how to use the menu, refer to “Introducing the menu system” on page 14 and “How to use the menu” on page 15.

## Changing the Channel Preset (CH PRESET) setting


The CH PRESET menu allows you to adjust the setup of your TV. For example, you can receive a channel with a weak signal that fails to be tuned in by automatic presetting.



### Presetting channels manually

1 Press MENU.

2 Press + or - to select the CH PRESET icon (⚙️), then press ENTER.




3 Press + or - to select MANUAL PROGRAM, then press ENTER.



4 Select the program number to which you want to preset a channel.

(1) Make sure "PR" is selected, then press ENTER.




(2) Press + or - until the program number you want to preset (e.g., program number 10) appears on the menu, then press ENTER.




### Changing the Channel Preset (CH PRESET) setting (continued)

5 Select the desired channel.

(1) Press + or - to select either VHF LOW, VHF HIGH or UHF, then press ENTER.




(2) Press + or - until the desired channel picture appears on the TV screen, then press ENTER.




6 If the sound of the desired channel is abnormal, select the appropriate TV system.

(1) Press + or - to select TV SYS, then press ENTER.




(2) Press + or - until the sound becomes normal (e.g., M), then press ENTER.




continued

**7** If you are not satisfied with the picture and sound quality, you may improve them by using fine tuning.

(1) Press + or - to select FINE, then press ENTER.



(2) Press + or - to select MANUAL, then press ENTER.



(3) Press + or - until the picture and sound quality are optimal, then press ENTER.



The + or - icon on the menu flashes while tuning.

#### To return to the normal screen

Press MENU.

#### Note


- The TV system (TV SYS) and the fine tuning (FINE) settings are memorized for each program number.

#### Changing the Channel Preset (CH PRESET) setting (continued)


#### Changing other CH PRESET menu options

**1** Press MENU.

**2** Press + or - to select the CH PRESET icon (⚡), then press ENTER.



**3** Press + or - to select the desired option (e.g., SKIP), then press ENTER.



Select	To
AUTO PROGRAM	preset channels automatically.
MANUAL PROGRAM	preset channels manually. See "Presetting channels manually" on page 21 and 22.
TV SYS	select the TV system. See "Presetting channels manually" on page 21 and 22.
COL SYS	select the color system. Normally, set this to "AUTO".
SKIP	skip unwanted or unused program numbers. 1 Press + or - until the unused or unwanted program number appears, then press ENTER. 2 Press + or - to select "ON", then press ENTER. To put the skipped program number back on, select "OFF", then press ENTER.

#### Tip

- For details on the menu system and how to use the menu, refer to "Introducing the menu system" on page 14 and "How to use the menu" on page 15.



#### Note

- If you preset a locked channel, that particular channel will be unlocked automatically (see page 19).


continued





## Additional Information

### Self-diagnosis function

Your TV is equipped with a self-diagnosis function. If there is a problem with your TV, the  indicator flashes red. The number of times the  indicator flashes indicates the possible causes.

Front of TV



















- 1 Check that the  indicator flashes red a number of times between 3-second intervals.
- 2 Count the number of times the  indicator flashes.
- 3 Press  (main power) to turn off your TV.
- 4 Inform your nearest Sony service center about the number of times the  indicator flashes.  
Be sure to note the model name and serial number located on the rear of your TV.

Additional Information


### Troubleshooting

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer .

Symptom	Solutions	Possible cause
Snowy picture 	<ul style="list-style-type: none"> <li>Check the antenna cable and connection on the TV, VCR and on the wall. (page 4)</li> <li>Display the CH PRESET menu and select "MANUAL PROGRAM" to preset the channel again. (page 21)</li> </ul>	<ul style="list-style-type: none"> <li>Connection is loose or the cable is damaged.</li> <li>Channel presetting is inappropriate or incomplete.</li> </ul>
Noisy sound 	<ul style="list-style-type: none"> <li>Check the antenna type (VHF/UHF). Contact a Sony dealer for advice.</li> <li>Adjust the antenna direction. Contact a Sony dealer for advice.</li> <li>Try using a booster.</li> </ul>	<ul style="list-style-type: none"> <li>The antenna type is inappropriate.</li> <li>The antenna direction is inappropriate.</li> <li>Signal transmission is low.</li> </ul>
Distorted picture 	<ul style="list-style-type: none"> <li>Turn off or disconnect the booster if it is in use.</li> </ul>	<ul style="list-style-type: none"> <li>Broadcast signals are too strong.</li> </ul>
Noisy sound 		
Good picture 	<ul style="list-style-type: none"> <li>If the sound of some channels are noisy, select the channel, then display the CH PRESET menu and select the appropriate TV system (TV SYS). (page 22)</li> </ul>	<ul style="list-style-type: none"> <li>The TV system (TV SYS) setting is inappropriate.</li> </ul>
Noisy sound 		
No picture 	<ul style="list-style-type: none"> <li>Check the power cord, antenna and the VCR connections.</li> <li>Press  (power).</li> <li>Press  (main power) on the TV to turn off the TV for about five seconds, then turn it on again.</li> </ul>	<ul style="list-style-type: none"> <li>The power cord, antenna or VCR is not connected.</li> <li>The TV is not turned on.</li> </ul>
No sound 		

Symptom	Solutions	Possible cause
Good picture 	<ul style="list-style-type: none"> <li>Press <math>\triangle</math> + to increase the volume level.</li> <li>Press <math>\otimes</math> to cancel the muting.</li> </ul>	<ul style="list-style-type: none"> <li>The volume level is too low.</li> <li>The sound is muted.</li> </ul>
No sound 		
Dotted lines or stripes 	<ul style="list-style-type: none"> <li>Do not use a hair dryer or other equipment near the TV.</li> <li>Adjust the antenna direction for minimum interference. Contact a Sony dealer for advice.</li> </ul>	<ul style="list-style-type: none"> <li>There is local interference from cars, neon signs, hair dryers, power generators, etc.</li> </ul>
Double images or "ghosts" 	<ul style="list-style-type: none"> <li>Use a highly directional antenna.</li> <li>Adjust the antenna direction. Contact a Sony dealer for advice.</li> <li>Turn off or disconnect the booster if it is in use.</li> </ul>	<ul style="list-style-type: none"> <li>Broadcast signals are reflected by nearby mountains or buildings.</li> <li>The antenna direction is inappropriate.</li> <li>Use of a booster is inappropriate.</li> </ul>
No color 	<ul style="list-style-type: none"> <li>Display the A/V CONTROL menu and select "ADJUST" of PICTURE MODE, then adjust the COLOR level. (pages 16 and 17)</li> <li>Display the CH PRESET menu and check the color system (COL SYS) setting (usually set this to AUTO). (page 24)</li> <li>Adjust the antenna direction. Contact a Sony dealer for advice.</li> </ul>	<ul style="list-style-type: none"> <li>The color level setting is too low.</li> <li>The color system setting is inappropriate.</li> <li>The antenna direction is inappropriate.</li> </ul>
Abnormal color patches 	<ul style="list-style-type: none"> <li>Keep external speakers or other electrical equipment away from the TV. Do not move the TV while the TV is turned on. Press <math>\textcircled{1}</math> (main power) on the TV to turn off the TV for about five minutes, then turn it on again.</li> </ul>	<ul style="list-style-type: none"> <li>The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.</li> </ul>

**Troubleshooting (continued)**


Symptom	Solutions	Possible cause
Picture slant 	<ul style="list-style-type: none"> <li>Display the SET UP menu and adjust "PIC ROTATION" so that the picture is aligned to the TV screen. (page 20)</li> </ul>	<ul style="list-style-type: none"> <li>The terrestrial magnetism affects your TV set.</li> </ul>
The $\textcircled{1}$ indicator on your TV flashes red a number of times between 3-second intervals.	<ul style="list-style-type: none"> <li>Contact your nearest Sony service center. (page 25)</li> </ul>	<ul style="list-style-type: none"> <li>Your TV may need service.</li> </ul>
TV cabinet creaks.	—	<ul style="list-style-type: none"> <li>Changes in room temperature sometimes make the TV cabinet expand or contract, making a noise. This does not indicate a malfunction.</li> </ul>
A "boom" sound is heard when the TV is turned on.	—	<ul style="list-style-type: none"> <li>The TV's demagnetizing function is working. This does not indicate a malfunction.</li> </ul>

continued

# Identifying parts and controls

Refer to the pages indicated in parentheses ( ) for details.

## Front panel




- 1 ① (main power) button (8)
- 2 PROGR +/- (program) buttons (8)
- 3 +/- (volume) buttons (8)
- 4 TV/video button (9)
- 5 AUTO PROGR (program) button (5)
- 6 MENU button (15)
- 7 (headphone) jack


continued

# Identifying parts and controls (continued)

## Remote Control



- 1 ✖ (muting) button (9)
- 2 (display) button (9)
- 3 (power) button (8)
- 4 (video) button (9)
- 5 (TV) button (9)
- 6 Number buttons (8)
- 7 JUMP button (9)
- 8 Menu operation buttons (15)  
MENU button  
+ or - buttons  
ENTER button
- 9 PROGR +/- button (8)
- 10 A/B button  
(not used for KV-XF29M80/  
XF29M50/XF25M80/XF25M50)
- 11 Timer setting buttons (10)  
(wake up timer)  
(sleep timer)
- 12 +/- (volume) buttons (8)




- 13 SOUND MODE button (11)
- 14 SURROUND button (13)
- 15 FAVORITE button (12)
- 16 PIC MODE button (11)
- 17 Teletext operation buttons  
(not used for KV-XF29M80/XF29M50/  
XF25M80/XF25M50)  
(text) (enlarge)  
(reveal) (hold)  
(index) (text clear)  
(FASTEXT: red, green, yellow, blue)


Names/symbols of buttons on the remote are indicated in different colors to represent the available functions.	
Label color	Button function
White	For general TV operations
Green	For Teletext operations

## SECTION 2 DISASSEMBLY


### 2-1. REAR COVER REMOVAL




### 2-2. SPEAKER BRACKET REMOVAL



### 2-3. CHASSIS ASSY REMOVAL




### 2-4. F BRACKET REMOVAL



2-5. SERVICE POSITION


(Note: Remove F Bracket first.)




2-6. REPLACEMENT OF PARTS

For replacement of the Control Button and Light Guide, unscrew them, exchange with the new parts, and fix them with screws (+BVTP) respectively.


2-6-1. REPLACEMENT OF CONTROL BUTTON



2-6-2. REPLACEMENT OF LIGHT GUIDE




2-7. TERMINAL BRACKET REMOVAL







## 2-8. H3 BOARD REMOVAL



## 2-9. A AND B3 BOARDS REMOVAL




## 2-10. PICTURE TUBE REMOVAL




## •REMOVAL OF ANODE-CAP

NOTE : After removing the anode, short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT.


## •REMOVING PROCEDURES



- ① Turn up one side of the rubber cap in the direction indicated by the arrow (a).




- ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow (b).



- ③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow (c).

## • HOW TO HANDLE AN ANODE-CAP

- ① Do not damage the surface of anode-caps with sharp shaped objects.
- ② Do not press the rubber too hard so as not to damage the inside of anode-cap. A metal fitting called the shatter-hook terminal is built into the rubber.
- ③ Do not turn the foot of rubber over too hard. The shatter-hook terminal will stick out or damage the rubber.



## SECTION 3

### SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switches should be set as follows unless otherwise noted:

PICTURE control ..... normal

BRIGHTNESS control ..... normal

Perform the adjustments in the following order :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

**Note :** Test Equipment Required.

1. Color-bar/Pattern Generator
2. Degausser
3. Oscilloscope

#### Preparation :

- In order to reduce the influence of geomagnetism on the set's picture tube, face it east or west.
- Switch on the set's power and degauss with the degausser.

#### 3-1. BEAM LANDING

1. Input a white signal with the pattern generator.  

Contrast	} normal
Brightness	
2. Position neck assy as shown in Fig3-2.
3. Set the pattern generator raster signal to a green raster.
4. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side.  
(See Figures 3-1 through 3-4.)
5. Move the deflection yoke forward and adjust so that the entire screen is green. (See Figure 3-2.)
6. Switch the raster signal to blue, then to red and verify the condition.
7. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws and DY spacers.
8. If the beam does not land correctly in all the corners, use a magnet to adjust it.  
(See Figure 3-5.)




Fig. 3-1




Fig. 3-2




Fig. 3-3




Fig. 3-4





Fig. 3-5

### 3-2. CONVERGENCE


#### Preparation :

- Before starting this adjustment, adjust the focus, horizontal size and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.


#### (1) Horizontal and Vertical Static Convergence




1. (Moving horizontally), adjust the H.STAT control so that the red, green and blue dots are on top of each other at the center of the screen.
2. (Moving vertically), adjust the V.STAT magnet so that the red, green and blue dots are on top of each other at the center of the screen.
3. If the H.STAT variable resistor cannot bring the red, green and blue dots together at the center of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V.STAT magnet in the manner given below.  
(In this case, the H.STAT variable resistor and the V.STAT magnet influence each other, so be sure to perform adjustments while tracking.)




#### ① V. STAT



#### ② H. STAT VR







#### ③



④ BMC (Hexapole) Magnet.

If the red, green and blue dots are not balanced or aligned, then use the BMC magnet to adjust in the manner described below.



**Note**

1. The Red and Blue magnets should be equally far from the horizontal center line.
2. Do not separate the Red and Blue magnets too far. (Less than 8 mm)


⑤ Y separation axis correction magnet adjustment.

1. Receive the cross-hatch signal and adjust [PICTURE] to [MIN] and [BRIGHTNESS] to [STANDARD] .
2. Adjust the Y separation axis correction magnet on the neck assembly so that the horizontal lines at the top and bottom of the screen are straight.


(2) Dynamic Convergence Adjustment

**Preparation:**


- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence




TLH



TLV




YCH



XCV


TLV	Rotate	TLV-2	VOL (29", 34") on DY
	Rotate	TLV	VOL (25") on DY
XCV	Rotate	XCV	Adj core on DY
YCH	Rotate	YCH	VOL on DY
TLH	Insert	TLH	Correction Plate to DY Pocket (Left or Right)

ON DY:




### 3-3. FOCUS ADJUSTMENT


Adjust FOCUS control on the flyback transformer for the best focus.



### (3) Screen-corner Convergence




Fix a Permalloy assy corresponding to the misconverged areas.



### 3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS

#### 1. G2 (SCREEN) ADJUSTMENT

- 1) Set the PICTURE to normal.
- 2) Put to VIDEO input mode without signals.
- 3) Connect R, G and B of the C board cathode to the oscilloscope.
- 4) Adjust BRIGHTNESS to obtain the cathode voltage to the value below.
- 5) Adjust G2 (screen) on the FBT until picture shows the point before cut off.




#### 2. WHITE BALANCE ADJUSTMENT

- 1) Set to Service Mode (Refer Section 4-1: ADJUSTMENTS WITH COMMANDER).
- 2) Input white raster signal.
- 3) Set the PICTURE to minimum.
- 4) Select GCT (WHB 4) and BCT (WHB 5) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 5) Set the PICTURE to maximum.
- 6) Select GDR (WHB 1) and BDR (WHB 2) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 7) Write into the memory by pressing [MUTING] then [0].

#### 3. SUB BRIGHT ADJUSTMENT

- 1) Set to service mode.
- 2) Input a staircase signal of black to white from the pattern generator.
- 3) BRIGHTNESS ....50%.  
PICTURE .....MINIMUM
- 4) Select SBR (WHB7) with [1] and [4], and adjust SBR (WHB7) level with [3] and [6] so that the second stripe from the right is dimly lit.




## SECTION 4

### CIRCUIT ADJUSTMENTS

#### 4-1. ADJUSTMENTS WITH COMMANDER

Service adjustments are made with the RM-954 that comes with these units.

##### a. ENTERING SERVICE MODE



##### b. METHOD OF CANCELLATION FROM SERVICE MODE

Set the standby condition (Press [POWER] button on the commander), then press [POWER] button again, hereupon it becomes TV mode.



##### c. METHOD OF WRITE INTO MEMORY

- 1) Set to Service Mode.
- 2) Press [1] (UP) and [4] (DOWN), select an item of adjustment.
- 3) Press [MUTING] button and it will indicate WRITE on the screen.
- 4) Press [0] button to write into memory.


##### d. MEMORY WRITE CONFIRMATION METHOD

- 1) After adjustment, pull out the plug from AC outlet, and then plug into AC outlet again.
- 2) Turn the power switch ON and set to Service Mode.
- 3) Call the adjusted items again to confirm adjustments were made.

The screen display is :



- [7], [0] All the data becomes the values in memory.
- [8], [0] All user control goes to the standard state.
- [5], [0] Service data initialization (Be sure not to use usually.)
- [2], [0] Write 50Hz adjustment data to 60Hz, or vice versa.



RM-954





4-2. ADJUSTMENT METHOD


Item Number 00 of device GEO

This explanation uses H-Position as an example.

- 1. Select “GEO 00 HPS” with the [1] and [4] buttons.
- 2. Raise/lower the data with the [3] and [6] buttons.
- 3. Select the optimum state. (The standard is 1F for PAL reception.)
- 4. Write with the [MUTING] button. (The display changes to WRITE.)
- 5. Execute the writing with the [0] button. (The WRITE display will be changed to red color while excuting, and back to SERVICE.)



Written with [MUTING]



Write executed with [0]

Use the same method for all Items. Use [1] and [4] to select the adjustment item, use [3] and [6] to adjust, write with [MUTING], then execute the write with [0].

- Note :**
- 1. In [WRITE], the data for all items are written into memory together.
  - 2. For adjustment items that have different standard data between 50Hz or 60Hz, be sure to use the respective input signal after adjustment.

**Adjustment Item Table**

Device Name	Functionality		Note	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)
	No	Name							
GEO	0	HPS	7	3F	H Position	50/60HZ	12 (7-2)	CXA2139S(88H)	96 (7-2)
	1	HSZ	1F	3F	H Size	50/60HZ	11 (7-2)		95 (7-2)
	2	PAP	1F	3F	Pin Amp	50/60HZ	13 (7-2)		97 (7-2)
	3	TLT	7	0F	Trapezium	50/60HZ	15 (7-4)		99 (7-4)
	4	VPS	1F	3F	V Position	50/60HZ	0F (7-2)		93 (7-2)
	5	VSZ	1F	3F	V Size	50/60HZ	0E (7-2)		92 (7-2)
	6	SCO	7	0F	S Correction	50/60HZ	10 (7-4)		94 (7-4)
	7	VLN	7	0F	V Linearity	50/60HZ	10 (3-0)		94 (3-0)
	8	BOW	7	0F	AFC Bow	50/60HZ	16 (7-4)		9A (7-4)
	9	AGL	7	0F	AFC-Angle	50/60HZ	16 (3-0)		9A (3-0)
	0A	UPN	1F	3F	Upper Pin	50/60HZ	14 (7-2)		98 (7-2)
	0B	LPN	2F	3F	Lower Pin	50/60HZ	18 (7-2)		9C (7-2)
	0C	HBL	0	1	H Blanking on/off		18 (1)		6C (1)
	0D	LBL	0F/0F	0F	Left H Blanking	50/60HZ	17 (7-4)		9B (7-4)
	0E	RBL	02/02	0F	Right H Blanking	50/60HZ	17 (3-0)		9B (3-0)
WHB	0	RDR	25/2A	3F	R Drive	DYNAMIC/other	09 (7-2)	CXA2139S(88H)	A3 (7-2)
	1	GDR	1F	3F	G Drive	DYNAMIC/other	0A (7-2)		A4 (7-2)
	2	BDR	1F	3F	B Drive	DYNAMIC/other	0B (7-2)		A5 (7-2)
	3	RCT	7	0F	R Cutoff	SECAM/other	07 (3-0)		A7 (3-0)
	4	GCT	7	0F	G Cutoff	SECAM/other	08 (7-4)		A8 (7-4)
	5	BCT	7	0F	B Cutoff	SECAM/other	08 (3-0)		A8 (3-0)
	6	BMN	15	1F	Brightness Minimum Data		06 (7-2)		106
	7	SBR	1F	3F	Sub Brightness Control		06 (7-2)		107
SAJ	0	PMX	36	3F	Picture Maximum Data		03 (7-2)	CXA2139S(88H)	105
	1	SHU	8	0F	Sub Hue Control	TV/Video	05 (7-2)		108
	2	SSH	03/05	0F	Sub Sharpness Control	TV/Video	07 (7-4)		109
	3	SCL	1F	3F	Sub Color Control	NTSC/others	04 (7-2)		10A
VP	0	EHT	02/02	0F	EHT Comp	50/60HZ	15 (3-0)	CXA2139S(88H)	99 (3-0)
	1	GMA		03	Gamma Correction	NTSC/others	0B (1-0)		25B (1-0)
	2	YDL	06/09/08	0FY Delay	(Separated in Standard mode) PAL/SECAM/NTSC	0C (3-0)			A0(3-0)
	3	SST	1	03	SECAM ID Start Position		1B (1-0)		6F (1-0)
	4	SSP	1	03	SECAM ID Stop Position		1B (3-2)		6F (3-2)
	5	SLV	2	03	SECAM ID Level		1C (1-0)		70 (1-0)
	6	SBF	22	3F	SECAM BELL f0		1C (7-2)		70 (7-2)
	7	DYC	1	1	Dynamic Color on/off		0A (1)		5E (1)
	8	ABL	1	1	ABL Mode Switching (except STANDARD mode)		09 (1)		5D (1)
	9	VTH	1	1	ABL Detection Vth Switching		09 (0)		5D (0)
	0A	SFO	1	1	FO Switching for Sharpness	NTSC/others	05 (1)		24A (1)
	0B	DCX	1	1	DC Trans. Ratio Switching		06 (1)		5A (1)
	0C	SHT	1	1	Pre-/Overshoot ratio Switch	NTSC/others	06 (0)		24A (0)

Adjustment Item Table

Device Name	Functionality		Note	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)
	No	Name							
VP	0D	HDW	0	1	H Drive Pulse Width Switch	TV/Video/Text	00 (6)		54 (6)
	0E	AFC	01/00	03	AFC Gain Control		0F (1-0)		A1 (1-0)
	0F	HOS	7	0F	H Oscillation		0C (7-4)		60 (7-4)
	10	HSS	0	1	Slice Level of H Sync Sep.		0D (1)		61 (1)
	11	VSS	0	1	Slice Level of V Sync Sep.	50/60Hz	0D (0)		61 (0)
	12	HMS	1	1	Macro Vision C/m off/on		0E (0)		92 (0)
	13	YUV	00/01	1	YUV Switch Control		01 (0)		55 (0)
	14	CDV	1	3	CD mode for Video and RF under no signal	Video only	0D (5-4)		259 (5-4)
	15	RON	1	1	R ON	not memorized	01 (3)		55 (3)
	16	GON	1	1	G ON	not memorized	01 (2)		55 (2)
	17	BON	1	1	B ON	not memorized	01 (1)		55 (1)
	18	PON	1	1	P ON	not memorized	00 (7)		54 (7)
	19	BLK	0	1	BLK Off		12 (0)		66 (0)
	1A	VMC	0	1	VM Off		13 (0)		67 (0)
AP	0	BCS	01	3	Bass Center Shift		#4 (3-0)	TDA7315(80H)	24C (1-0)
	1	TCS	02	3	Treble Center Shift		#5 (3-0)		24D (1-0)
	2	TRF	03	3	RF Treble Offset		#5 (3-0)		256 (1-0)
MSP	0	WST	15	FF	W/G Stereo Threshold			MSP3415D(84H)	165
	1	WBT	EC	FF	W/G Bilingual Threshold				166
	2	WLL	5	FF	W/G Monaural Threshold				167
	3	WAC	1	0F	W/G Agreement Count				168
	4	WDL	30	FF	W/G Search Delay				169
	5	NDL	20	FF	NICAM Search Delay				16A
	6	SDL	10	FF	Stereo status Read Delay				16B
	7	AGC	1	1	AGC Switch Auto/Constant		00BB (7)		116 (7)
	8	REL	28	3F	AGC Gain at Constant Mode		00BB (6-1)		116 (6-1)
	9	CRM	0	1	Carrier muting on/off		00BB (9)		115 (9)
	0A	ACO	1	1	Audio Clock out on/off		0083 (5)		11A (5)
	0B	FP	1B	7F	FM Prescale for non-M system		000E (14-8)		221
	0C	FPM	32	7F	FM Prescale for M system		000E (14-8)		222
	0D	FH	36	7F	FM Prescale for HDEV		000E (14-8)		223
	0E	FHM	65	7F	FM Prescale for HDEV and M		000E (14-8)		224
	0F	WGP	2A	7F	W/G Prescale		000E (14-8)		225
	10	NIP	6D	7F	NICAM Prescale		0010 (14-8)		14F
	11	ERR	50	FF	Auto FM switch Threshold		0021 (10-3)		174
	12	VOL	6D	FF	Loud Speaker gain 7000 to 7f0h		0000 (15-4)		252

**Adjustment Item Table**

Device Name	Functionality		Note	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)
	No	Name							
SVP	0	SBF	22	3F	SECAM BELL f0	TV/Video NTSC/Others	1C (7-2)	CXA2060AS(8AH)	85 (7-2)
	1	HOS	7	0F	H Oscillation		0C (7-4)		80 (7-4)
	2	SHU	8	0F	Sub Hue Control		05 (7-2)		210
	3	SCL	1F	3F	Sub Color Control		04 (7-2)		211
PIP	0	SDL	02	0F	Delay of output SELECT		01 (6-3)	SDA9288X(D6H)	18E (6-3)
	1	PPH	15	FF	H Position of TOP-LEFT Pin P		01/02		19D
	2	PPV	2E	FF	V Position of TOP-LEFT Pin P		03 (7-0)		19E
	3	YDL	0	07	Delay of Luminance Input		04 (2-0)		191 (2-0)
	4	HDI	3	0F	H Sync Delay for Inset		06 (3-0)		193 (3-0)
	5	ISC	01	1	Inset Clock Selection		06 (4)		193 (4)
	6	CLP	1	1	Clamp Pulse Selection		06 (5)		193 (5)
	7	CLC	0	1	Clamp Cycle Selection		06 (6)		193 (6)
	8	CON	0D	0F	Contrast Adjustment for inset		09 (7-4)		196 (7-4)
	9	PLL	2	03	H Position For A-ch		0D (6-5)		19A (6-5)
	0A	PDV	0	0F	PIP V Pedestal Level		0E (7-4)		19B (7-4)
	0B	PDU	0	0F	PIP U Pedestal Level		0E (3-0)		19B (3-0)
TXT	0	TXH	1	3	Teletext Horizontal Position		10 (1-0)	SAA5261(58H)	248 (1-0)
	1	TXV	0	3	Teletext Vertical Position		10 (6-4)		248 (5-4)
OPM	0	OSH	0A	3F	OSD H Position	Option-Misc	1F1	CXP86461(60H)	17B (7-2)
	1	COM	1	03	Comb Selection				23F (7-6)
	2	APC	1	1	APC Switch				23E (5)
	3	TSY	0	03	TV Sys at Auto TV Sys				23E (4-3)
	4	MUT	0	1	No Signal Mute				23E (0)
	5	AFM	1	1	Auto FM switch				23E (1)
	6	RFB	0	3	C-BPF Control				23F (5-4)
	7	TVO	0	7	Tilt to V-Angle offset				23F (2-0)
OPB	8	DBL	0	1	Disable Blue Black Function	Option-Bits		CXP86461(60H)	23E (2)
	0	OP1	FF	FF	Optional Bits 1 (see below)				48
	1	OP2	E3	FF	Optional Bits 2 (see below)				49
	2	OP3	0	FF	Optional Bits 3 (see below)				4A

**NOTE**

- ■ shaded items are fixed data.
- Standard data listed on the Adjustment Item Table are reference values, therefore it may be different for each model and for each mode.
- Note for Different Data Those are the standard data values written on the microprocessor. Therefore, the data values of the modes and stored respectively in the memory.  
In case of a device replacement, adjustment by rewriting the data value is necessary for some items.

**KV-XF25M50/XF25M80**

RM-954

**ITEM INFORMATION.****No. OPB0 OP1**

Item	XTAL 4.43	XTAL 3.58	SECAM	2nd. Lang	B/G	I	D/K	M
<b>KV-XF25M50</b>	1	1	1	1	1	1	1	1
<b>KV-XF25M80</b>	1	1	1	1	1	1	1	1

**No. OPB1 OP2**

Item	TOP	NICAM	HDEV	Thai Bil	Dis Fav.	DVD Input	AV Input	
<b>KV-XF25M50</b>	0	0	0	0	0	0	1	1
<b>KV-XF25M80</b>	0	0	0	0	0	0	1	1


**No. OPB2 OP3**

Item	Pic rot	2199 Curve	Auto PIC	Auto TV sys	US ST	AV Mono	11 KEY	Color SW
<b>KV-XF25M50</b>	0	0	1	0	0	0	0	0
<b>KV-XF25M80</b>	0	0	1	0	0	0	0	0

### 4-3. PICTURE QUALITY ADJUSTMENTS


#### SUB COLOR ADJUSTMENT

1. Input a PAL color-bar.
2. Set to the following condition:  
PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
3. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
4. Set to Service Mode and select SAJ 3 'SCL' with [1] and [4] of the commander then adjust to VB2=VB3=VB4 with [3] and [6].
5. Press [MUTING] → [0] of the commander to write the data.
6. Adjust SAJ 3 'SCL' as step 2 to 5 when receiving NTSC color-bar.



#### SUB HUE ADJUSTMENT


1. Select Video 1.
2. Input a NTSC color-bar, video into Video 1.
3. Set the following condition:  
PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
4. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
5. Select SAJ 1 'SHU' with [1] and [4] of the commander by setting to Service Mode and adjust to VB1=VB2=VB3=VB4 with [3] and [6].



6. Press [MUTING] → [0] of the commander to write the data.

#### BELL FILTER ADJUSTMENT

1. Input SECAM color-bar signal.
2. Connect the dual-trace oscilloscope to the pin ⑨ (R-Y) of CN303 (not mounted).
3. Adjust SERVICE MODE, ITEMS 'SBF' as shown below.



### 4-4. A BOARD ADJUSTMENT AFTER IC003 (MEMORY) REPLACEMENT


1. Enter to Service Mode.
2. Press commander buttons [5] and [0] (Data Initialize), and [2] and [0] (Data Copy) to initialize the data.
3. Call each item number and check if the respective screen shows the normal picture.  
In cases where items are not well adjusted, rectify the items with fine adjustment.  
Write the data per each item number ([MUTING] + [0]).
4. Select item numbers "OPB0" (OP1), "OPB1" (OP2) and "OPB2" (OP3) and respectively set the bit per model with command buttons [3] and [6].
5. Press commander buttons [8] and [0] (Test Normal) to return to the data that was set on the shipment from the factory.  
(This will also cancel Service Mode.)

4-5. PICTURE DISTORTION ADJUSTMENT (1)

Item Number 00 – 0B


00

HPS (H POSITION)




01

HSZ (H SIZE)




02

PAP (PIN AMP)




03

CNP (CORNER PIN)




05

VPS (V POSITION)




06

VSZ (V SIZE)




07

SCO (VERTICAL S-Correction)




08

VLN (V LINEARITY)




0B

BOW (AFC.BOW)




0C

AGL (AFC.ANGLE)



PICTURE DISTORTION ADJUSTMENT (2)

H-TRAPEZOID (Rotate RV1801)











5-1. BLOCK DIAGRAM

SECTION 5  
DIAGRAM





5-3. CIRCUIT BOARDS LOCATION



5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

- Note:**
- All capacitors are in  $\mu\text{F}$  unless otherwise noted.
  - All electrolytic capacitors are rated at 50V unless otherwise noted.
  - All resistors are in ohms.  
 $\text{k}\Omega = 1000\Omega$ ,  $\text{M}\Omega = 1000\text{k}\Omega$
  - Indication of resistance which does not have rating electrical power is as follows.
- Pitch: 5 mm  
Rating electrical power 1/4W (CHIP: 1/10W)

: nonflammable resistor.


: internal component.

: panel designation or adjustment for repair.


Reference information		
RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: ⋈	ADJUSTMENT RESISTOR
	: LF-8L	MICRO INDUCTOR
	: TA	TANTALUM
COIL	: PS	STYROL
	: PP	POLYPROPYLENE
CAPACITOR	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

**Note: The component identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.**

A BOARD WAVEFORMS




A BOARD IC001 CXP86461-621S




Schematic diagram

A(1/2) board →

### (1) Schematic Diagram of A(1/2) Board



(2) Schematic Diagram of A(2/2) Board




Schematic diagram

← A(2/2) board



(3) Schematic Diagram of B2 Board




A BOARD

IC	D004	D-8	D615	E-7
IC001	B-10	D005	D006	E-9
IC002	C-10	D006	D006	E-9
IC003	A-9	D100	D100	F-8
IC100	B-5	D203	D203	F-9
IC201	B-11	D300	D300	F-9
IC203	B-3	D301	D301	F-8
IC204	B-2	D302	D302	F-12
IC301	B-6	D303	D303	E-12
IC503	J-5	D304	D304	D-12
IC601	J-8	D305	D305	F-8
IC602	H-6	D306	D306	G-5
IC603	D-8	D307	D307	F-9
IC604	D-10	D308	D308	E-10
IC901	I-13	D309	D309	G-12
		D310	D310	F-12
		D311	D311	E-12
		D312	D312	F-11
		D313	D313	E-12
		D315	D315	D-12
		D316	D316	F-11
		D317	D317	E-11
		D319	D319	C-13
		D320	D320	C-13
		D321	D321	D-13
		D401	D401	F-13
		D402	D402	I-13
		D403	D403	
		D404	D404	
		D405	D405	
		D406	D406	
		D407	D407	
		D408	D408	
		D409	D409	
		D504	D504	
		D505	D505	
		D506	D506	
		D507	D507	
		D508	D508	
		D509	D509	
		D510	D510	
		D511	D511	
		D512	D512	
		D513	D513	
		D517	D517	
		D518	D518	
		D519	D519	
		D520	D520	
		D521	D521	
		D522	D522	
		D523	D523	
		D525	D525	
		D527	D527	
		D528	D528	
		D529	D529	
		D530	D530	
		D531	D531	
		D532	D532	
		D533	D533	
		D534	D534	
		D600	D600	
		D601	D601	
		D602	D602	
		D603	D603	
		D604	D604	
		D605	D605	
		D606	D606	
		D607	D607	
		D608	D608	
		D609	D609	
		D611	D611	
		D612	D612	
		D613	D613	

**B2** [COMB FILTER] **A** [POWER SUPPLY, HV, MICON, Y/C JUNGLE]



PRINTED WIRING BOARDS

- A Board -





(4) Schematic Diagrams of H3 and VM1 Boards




PRINTED WIRING BOARDS


VM1 [VELOCITY MODULATION]

H3 [FUNCTION KEY]

– VM1 Board –




– H3 Board –






**(5) Schematic Diagram of B3 Board**




**B3** [AUDIO PROSESSOR, AV SWITCH]

**B3 BOARD IC3201 NJM2187L**



**- B3 Board -**




### Schematic diagram

**F** board ➡




(6) Schematic Diagram of F Board




PRINTED WIRING BOARD

**F** [CISPR]


– F Board –




C BOARD IC701 STV5112



C BOARD WAVEFORMS



(7) Schematic Diagram of C Board




**C**  
(RGB OUT)

PRINTED WIRING BOARD

**C** [RGB OUT]


- C Board -




5-5. SEMICONDUCTORS

DIODE


AU-01Z-V1  
EL1Z  
ERA22-08  
GP08D  
NNCD9.1A-T1  
RD33EB3T  
RGP02-17EL-6433




D1NS4  
RD11ES-B3  
RD20ES-B2  
RD30ESB2  
RD39ES-B2  
RD6.8ES-B1  
1SS119-25  
11EQS04  
11ES2-7B5




D5S6M




FMX-12S




D3SB60




ERC04-06SE  
HSS8370  
RS3FS  
RU4AM-T4




DTZ-TT11-15B  
DTZ10B  
MA111-(K8).S0  
UDZS-TE17-5.1B  
UDZS-TE17-9.1B  
1SS355TE-17



5P6M




D3L60




TRANSISTOR


UN2111  
UN2211  
UN2213  
2SA1162-G  
2SC2712-YG  
2SD2114K




DTC144ESA  
2SA1175-HFE  
2SC2785-HFE




2SA1091-0




2SA1606-E  
2SC4159-E




IRF614




2SK246-GR




2SK2845-LB102




2SC2688-LK



2SD2578-CA




2SC2458-YGR  
2SD2144S-UVW




IC

CXA11315P (16PIN)  
CXA1855S (48PIN)  
CXA2139S (64PIN)  
CXP86461-621S (64PIN)  
M24C08-BN6(8PIN)  
NJM2150D (20PIN)  
NJM2187L (30PIN)  
STV5112 (15PIN)




Dual In-line Package  
Pin 6~98

MM1319AFBE (7PIN)  
NJM2903M (8PIN)  
NJU4066BM (14PIN)  
TDA7315D013TR (20PIN)  
μPC4558G2 (8PIN)




Small Out-line L-leaded Package  
Pin 8~98


SBX1981-51(21)



SE-135N




TDA8172




STR-F6656

MARKING SIDE VIEW




Zig-zag In -line Package  
Pin 6~99


TA8200AH



LA6510



NJM7809-FA  
TA7805S



## SECTION 6

### EXPLODED VIEWS


#### NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

#### 6-1. SPEAKER BRACKET


- : 7-685-663-71 SCREW +BVTP 4 × 16  
●: 7-685-648-79 SCREW +BVTP 3 × 12



REF. NO.	PART NO.	DESCRIPTION	REMARK
1	4-302-404-03	SCREW (WASHER HEAD) (+P 4X16)	
2	1-529-190-11	SPEAKER (5CM)	
3	$\triangle$ 4-065-571-01	COVER, REAR	
4	1-503-902-11	SPEAKER (15 x 6.5CM)	
5	4-046-981-02	BRACKET, SPEAKER	
6	* 4-038-987-11	CUSHION, SPEAKER	

## 6-2. CHASSIS


●: 7-685-648-79 SCREW BVTP 3 × 12



REF. NO.	PART NO.	DESCRIPTION	REMARK
51	* A-1372-866-A	H3 BOARD, MOUNTED	
52	* A-1136-131-A	B3 BOARD, COMPLETE	
53	△ 4-022-115-21	HOLDER, AC CORD	
54	△ 1-574-062-61	CORD, POWER (WITH CONNECTOR) 2.5A/250V	
55	4-066-684-22	BRACKET, TERMINAL	
56	4-046-797-01	SCREW (3X12), (+)BVTAP	
57	* A-1131-417-A	B2 BOARD, MOUNTED	
58	* A-1299-314-A	A BOARD, COMPLETE	
59	△ 1-453-284-11	TRANSFORMER ASSY, FLYBACK (NX-4009//M314)	
60	* 4-066-681-04	BRACKET, MAIN	
61	* A-1241-361-A	F BOARD, MOUNTED	
62	* 4-066-682-01	BRACKET, F PWB	
63	8-598-449-10	TUNER, FSS BTF-LG433	

**6-3. PICTURE TUBE**

●: 7-685-648-79 SCREW BVTP 3 × 12



REF. NO.	PART NO.	DESCRIPTION	REMARK
101	X-4038-159-2	BEZNET ASSY	102-109, 128, 131
102	4-036-405-11	SPRING, COMPRESSION	
103	4-065-508-01	BUTTON, POWER	
104	4-047-464-01	CATCHER, PUSH	
105	4-067-062-01	DAMPER (2P)	
106	X-4035-862-4	HANDLE ASSY (R)	
107	X-4035-861-4	HANDLE ASSY (L)	
108	4-065-509-01	BUTTON, CONTROL	
109	* 4-065-510-01	GUIDE, LIGHT	
110	4-054-468-01	SHEET, BLOTTING	
111	△ 8-733-250-05	PICTURE TUBE (A60LPN70X)	
112	4-046-765-01	SCREW, TAPPING 7+CROWN WASHER	
113	* 3-704-372-41	HOLDER, HV CABLE	
114	4-046-600-11	SPACER, DY	
115	4-057-714-01	PIECE ASSY, TLH CORRECTION	

REF. NO.	PART NO.	DESCRIPTION	REMARK
116	△ 1-451-475-11	DEFLECTION YOKE (Y25RSA)	
117	* A-1331-911-A	C BOARD, MOUNTED	
118	△ 1-403-619-81	COIL, DEMAGNETIZATION	
119	* 4-069-320-01	CUSHION (50X290), DGC	
120	* 4-065-572-01	CLIP (25RSN), DGC	
121	4-061-369-01	HOLDER, DEGAUSE COIL	
122	1-452-896-61	COIL, NA ROTATION (RT-200)	
123	* A-1342-476-A	VM1 BOARD, MOUNTED	
124	4-369-318-61	SPRING, TENSION	
125	1-452-032-00	MAGNET, DISC	
126	1-452-014-11	CIRCULAR DISC MAGNET B	
127	4-051-734-42	PIECE B(120), CONV. CORRECT	
128	4-032-761-01	SHAFT (S), DOOR	
129	4-068-028-22	BAND, DGC	
130	8-453-011-21	NA299-S	
131	4-070-385-51	DOOR, CONTROL	



## SECTION 7

## ELECTRICAL PARTS LIST

A

## NOTE:

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

• Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

• All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

• All resistors are in ohms  
• F : nonflammable

## CAPACITORS

• MF :  $\mu$ F, PF :  $\mu$ F

## COILS

• MMH : mH, UH :  $\mu$ H

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	* A-1299-314-A	A BOARD COMPLETE *****		C303	1-125-798-91	ELECT	0.47UF 20.00% 63V
				C304	1-126-967-11	ELECT	47UF 20.00% 50V
	1-466-162-42	BLOCK, COM FILTER (CFB-4)		C305	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
	* 4-040-983-41	TERMINAL BOARD (D)		C306	1-163-233-51	CERAMIC CHIP	18PF 5.00% 50V
	4-382-854-11	SCREW (M3X10), P, SW (+)		C307	1-163-233-51	CERAMIC CHIP	18PF 5.00% 50V
	4-382-854-21	SCREW (M3X14), P, SW (+)		C308	1-163-125-00	CERAMIC CHIP	220PF 5.00% 50V
				C309	1-126-957-11	ELECT	0.22UF 20.00% 50V
		<CAPACITOR>		C311	1-125-797-91	ELECT	10UF 20.00% 50V
C004	1-163-001-51	CERAMIC CHIP	220PF 10% 50V	C312	1-164-346-51	CERAMIC CHIP	1UF 10% 16V
C005	1-163-001-51	CERAMIC CHIP	220PF 10% 50V	C313	1-164-346-51	CERAMIC CHIP	1UF 10% 16V
C006	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V	C315	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
C007	1-104-664-11	ELECT	47UF 20.00% 16V	C316	1-104-664-11	ELECT	47UF 20.00% 25V
C013	1-164-232-11	CERAMIC CHIP	0.01UF 10.00% 50V	C317	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
C014	1-104-664-11	ELECT	47UF 20.00% 25V	C318	1-163-031-11	CERAMIC CHIP	0.01UF 50V
C015	1-163-009-11	CERAMIC CHIP	0.001UF 10.00% 50V	C319	1-163-031-11	CERAMIC CHIP	0.01UF 50V
C016	1-163-243-11	CERAMIC CHIP	47PF 5.00% 50V	C320	1-163-031-11	CERAMIC CHIP	0.01UF 50V
C017	1-163-113-00	CERAMIC CHIP	68PF 10% 50V	C322	1-163-005-51	CERAMIC CHIP	470PF 10% 50V
C019	1-104-664-11	ELECT	47UF 20.00% 25V	C323	1-126-965-11	ELECT	22UF 20.00% 50V
C022	1-163-227-51	CERAMIC CHIP	10PF 0.50PF 50V	C324	1-163-017-00	CERAMIC CHIP	0.0047UF 10.00% 50V
C023	1-163-227-51	CERAMIC CHIP	10PF 0.50PF 50V	C325	1-125-799-91	ELECT	1UF 20.00% 63V
C024	1-163-227-51	CERAMIC CHIP	10PF 0.50PF 50V	C327	1-126-965-11	ELECT	22UF 20.00% 50V
C026	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V	C328	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
C027	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V	C329	1-126-965-11	ELECT	22UF 20.00% 50V
C028	1-163-037-11	CERAMIC CHIP	0.022UF 10.00% 50V	C330	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
C030	1-126-965-11	ELECT	22UF 20.00% 50V	C331	1-125-805-91	ELECT	4.7UF 20.00% 50V
C031	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V	C332	1-125-805-91	ELECT	4.7UF 20.00% 50V
C032	1-107-823-51	CERAMIC CHIP	470000PF 10% 16V	C335	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
C034	1-163-031-11	CERAMIC CHIP	0.01UF 50V	C336	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V
C041	1-163-251-11	CERAMIC CHIP	100PF 5.00% 50V	C337	1-125-800-91	ELECT	2.2UF 20.00% 63V
C042	1-163-251-11	CERAMIC CHIP	100PF 5.00% 50V	C338	1-163-017-00	CERAMIC CHIP	0.0047UF 10.00% 50V
C043	1-163-251-11	CERAMIC CHIP	100PF 5.00% 50V	C341	1-115-340-51	CERAMIC CHIP	0.22UF 10.00% 25V
C044	1-163-251-11	CERAMIC CHIP	100PF 5.00% 50V	C342	1-163-125-00	CERAMIC CHIP	220PF 5.00% 50V
C047	1-163-251-11	CERAMIC CHIP	100PF 5.00% 50V	C502	1-163-275-11	CERAMIC CHIP	0.001UF 5.00% 50V
C103	1-164-004-51	CERAMIC CHIP	0.1UF 10.00% 25V	C506	1-107-638-11	ELECT	33UF 20.00% 160V
C104	1-104-665-11	ELECT	100UF 20.00% 10V	C507	1-161-830-00	CERAMIC	0.0047UF 500V
C107	1-163-005-51	CERAMIC CHIP	470PF 10% 50V	C510	1-102-112-00	CERAMIC	330PF 10.00% 50V
C108	1-104-664-11	ELECT	47UF 20.00% 16V	C513	1-163-263-51	CERAMIC CHIP	330PF 10% 50V
C109	1-163-005-51	CERAMIC CHIP	470PF 10% 50V	C514	1-106-383-00	MYLAR	0.047UF 10.00% 200V
C110	1-163-005-51	CERAMIC CHIP	470PF 10% 50V	C517	1-164-182-11	CERAMIC CHIP	3300PF 10% 50V
C111	1-163-005-51	CERAMIC CHIP	470PF 10% 50V	C518	1-104-665-11	ELECT	100UF 20.00% 10V
C112	1-104-664-11	ELECT	47UF 20.00% 16V	C519	1-102-212-00	CERAMIC	820PF 10.00% 500V
C113	1-104-664-11	ELECT	47UF 20.00% 25V	C521	1-126-934-11	ELECT	220UF 20.00% 16V
C114	1-126-967-11	ELECT	47UF 20.00% 50V	C522	1-126-933-11	ELECT	100UF 20.00% 16V
C300	1-164-505-11	CERAMIC CHIP	2.2UF 16V	C523	1-102-002-00	CERAMIC	680PF 10.00% 500V
C301	1-126-935-11	ELECT	470UF 20.00% 16V	C524	1-126-967-11	ELECT	47UF 20.00% 50V
C302	1-163-005-51	CERAMIC CHIP	470PF 10% 50V	C526	1-130-495-00	MYLAR	0.1UF 5.00% 50V
				C527	1-102-820-00	CERAMIC	330PF 5.00% 50V

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

A

REF.NO.	PART NO.	DESCRIPTION	REMARK	
C528	1-161-754-00	CERAMIC	0.001UF	10.00% 2KV
C530	1-137-372-11	MYLAR	0.022UF	5.00% 50V
C531	1-125-800-91	ELECT	2.2UF	20.00% 63V
C532	1-126-941-11	ELECT	470UF	20.00% 25V
C533	1-126-941-11	ELECT	470UF	20.00% 25V
C536	1-136-165-00	MYLAR	0.1UF	5.00% 50V
C537	1-126-969-11	ELECT	220UF	20.00% 50V
C538	1-136-617-11	FILM	0.019UF	3.00% 2KV
C539	1-130-959-61	FILM	0.047UF	5.00% 400V
C540	1-136-171-00	MYLAR	0.33UF	5.00% 50V
C546	1-165-319-11	CERAMIC CHIP	0.1UF	50V
C548	1-163-143-00	CERAMIC CHIP	0.0012UF	5.00% 50V
C549	1-163-017-00	CERAMIC CHIP	0.0047UF	10.00% 50V
C550	1-106-220-00	MYLAR	0.1UF	10.00% 100V
C551	1-125-799-91	ELECT	1UF	20.00% 63V
C552	1-162-116-00	CERAMIC	680PF	10.00% 2KV
C553	1-162-116-00	CERAMIC	680PF	10.00% 2KV
C554	1-137-417-11	MYLAR	0.0047UF	10.00% 200V
C556	1-126-941-11	ELECT	470UF	20.00% 25V
C557	1-126-941-11	ELECT	470UF	20.00% 25V
C558	1-123-024-21	ELECT	33UF	160V
C560	1-102-228-00	CERAMIC	470PF	10.00% 500V
C561	1-129-708-91	FILM	0.0033UF	5.00% 630V
C562	1-102-228-00	CERAMIC	470PF	10.00% 500V
C563	1-164-344-11	CERAMIC CHIP	0.068UF	10.00% 25V
C564	1-163-038-00	CERAMIC CHIP	0.1UF	25V
C565	1-107-655-11	ELECT	47UF	20.00% 250V
C566	1-102-244-00	CERAMIC	220PF	10.00% 500V
C567	1-115-520-11	FILM	0.68UF	5.00% 250V
C568	1-102-228-00	CERAMIC	470PF	10.00% 500V
C570	1-115-521-11	FILM	0.82UF	5.00% 250V
C572	1-107-846-11	FILM	0.1UF	5.00% 250V
C573	1-106-387-00	MYLAR	0.068UF	10.00% 200V
C574	1-107-636-11	ELECT	10UF	20.00% 160V
C576	1-130-495-00	MYLAR	0.1UF	5.00% 50V
C577	1-106-395-00	MYLAR	0.15UF	10.00% 200V
C582	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V
C586	1-216-295-61	SHORT CHIP	0	
C600 $\triangle$	1-104-705-11	MYLAR	0.1UF	20.00% 250V
C601	1-130-338-91	FILM	0.01UF	5.00% 630V
C602 $\triangle$	1-104-705-11	MYLAR	0.1UF	20.00% 250V
C603	1-104-664-11	ELECT	47UF	20.00% 25V
C604	1-163-009-11	CERAMIC CHIP	0.001UF	10.00% 50V
C605 $\triangle$	1-119-886-51	CERAMIC	470PF	10.00% 250V
C606 $\triangle$	1-119-886-51	CERAMIC	470PF	10.00% 250V
C607	1-161-830-00	CERAMIC	0.0047UF	99% 500V
C608	1-161-830-00	CERAMIC	0.0047UF	99% 500V
C609	1-126-968-11	ELECT	100UF	20.00% 50V
C610	1-125-797-91	ELECT	10UF	20.00% 50V
C611	1-161-830-00	CERAMIC	0.0047UF	99% 500V
C612	1-161-830-00	CERAMIC	0.0047UF	99% 500V
C613	1-125-906-11	ELECT	560UF	20.00% 450V
C614	1-125-797-91	ELECT	10UF	20.00% 50V
C615 $\triangle$	1-119-886-51	CERAMIC	470PF	10.00% 250V
C616	1-130-202-00	FILM	0.022UF	5.00% 400V
C617	1-107-792-11	CERAMIC	100PF	5.00% 1KV
C618	1-125-893-11	FILM	680PF	3.00% 1.5KV

REF.NO.	PART NO.	DESCRIPTION	REMARK	
C619 $\triangle$	1-119-886-51	CERAMIC	470PF	10.00% 250V
C620	1-163-133-00	CERAMIC CHIP	470PF	10% 50V
C621	1-102-114-00	CERAMIC	470PF	10.00% 50V
C622	1-102-119-00	CERAMIC	0.0015UF	10.00% 50V
C623	1-104-665-11	ELECT	100UF	20.00% 25V
C624	1-125-772-91	CERAMIC	1500PF	10.00% 2KV
C626	1-102-002-00	CERAMIC	680PF	10.00% 500V
C627	1-102-002-00	CERAMIC	680PF	10.00% 500V
C628	1-126-952-11	ELECT	1000UF	20.00% 35V
C629	1-125-797-91	ELECT	10UF	20.00% 50V
C630	1-125-494-11	ELECT(BLOCK)	560UF	20.00% 160V
C632	1-128-339-11	ELECT	2200UF	20.00% 16V
C633	1-104-999-11	MYLAR	0.1UF	10.00% 200V
C634	1-126-933-11	ELECT	100UF	20.00% 16V
C635	1-104-665-11	ELECT	100UF	20.00% 10V
C636	1-104-760-51	CERAMIC CHIP	0.047UF	10.00% 50V
C641	1-102-002-00	CERAMIC	680PF	10.00% 500V
C642	1-107-890-11	ELECT	2200UF	20.00% 25V
C643	1-104-665-11	ELECT	100UF	20.00% 10V
C644	1-104-331-11	CERAMIC	0.0022UF	10.00% 1KV
C645	1-137-605-11	MYLAR	0.01UF	10.00% 250V
C646	1-107-679-91	ELECT	10UF	20.00% 450V
C647	1-163-275-11	CERAMIC CHIP	0.001UF	5.00% 50V
C649	1-126-940-11	ELECT	330UF	20.00% 25V
C650	1-163-275-11	CERAMIC CHIP	0.001UF	5.00% 50V
C651	1-163-133-00	CERAMIC CHIP	470PF	10% 50V
C652	1-126-965-11	ELECT	22UF	20.00% 50V
C653	1-104-664-11	ELECT	47UF	20.00% 25V
C655 $\triangle$	1-119-886-51	CERAMIC	470PF	10.00% 250V
C657	1-101-821-00	CERAMIC	0.0022UF	500V
C912	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V
C913	1-104-665-11	ELECT	100UF	20.00% 10V
<CONNECTOR>				
CN101 *	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P		
CN102 *	1-779-889-11	CONNECTOR, BOARD TO BOARD 8P		
CN104	1-695-915-11	TAB (CONTACT)		
CN105 *	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P		
CN106 *	1-564-506-11	PLUG, CONNECTOR 3P		
CN201 *	1-564-508-11	PLUG, CONNECTOR 5P		
CN202 *	1-508-847-00	PIN, CONNECTOR 4P		
CN304 *	1-766-955-11	CONNECTOR, BOARD TO BOARD 11P		
CN305 *	1-564-509-11	PLUG, CONNECTOR 6P		
CN501 *	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P		
CN502 *	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P		
CN505	1-508-766-00	PIN, CONNECTOR (5MM PITCH) 4P		
CN507 *	1-564-509-11	PLUG, CONNECTOR 6P		
CN508	1-695-915-11	TAB (CONTACT)		
CN509	1-695-915-11	TAB (CONTACT)		
CN601 *	1-580-843-11	PIN, CONNECTOR (POWER)		
CN602 *	1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P		
CN603 *	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P		
CN604 *	1-573-963-11	PIN, CONNECTOR (PC BOARD) 3P		
CN608 *	1-564-507-11	PLUG, CONNECTOR 4P		
CN904 *	1-564-512-11	PLUG, CONNECTOR 9P		



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
		<DIODE>					
D001	8-719-988-61	DIODE 1SS355TE-17		D618	8-719-067-18	DIODE RN4Z	
D002	8-719-988-61	DIODE 1SS355TE-17		D620	8-719-110-72	DIODE RD30ES-T1B1	
D005	8-719-988-61	DIODE 1SS355TE-17		D621	8-719-071-38	DIODE D5S6M	
D006	1-216-295-61	SHORT CHIP 0		D622	8-719-077-49	DIODE D3L60	
D300	1-216-295-61	SHORT CHIP 0		D623	8-719-056-91	DIODE UDZ-TE-17-15B	
D301	8-719-988-61	DIODE 1SS355TE-17		D624	8-719-404-50	DIODE MA111-(K8).S0	
D303	8-719-988-61	DIODE 1SS355TE-17		D625	8-719-069-60	DIODE UDZS-TE17-10B	
D304	8-719-988-61	DIODE 1SS355TE-17		D627	8-719-067-18	DIODE RN4Z	
D305	8-719-988-61	DIODE 1SS355TE-17		D628	8-719-921-20	DIODE 1SS119-25TD	
D306	8-719-988-61	DIODE 1SS355TE-17		D631	8-719-068-00	DIODE ERC04-06SE	
D307	8-719-988-61	DIODE 1SS355TE-17		D632	8-719-068-00	DIODE ERC04-06SE	
D308	8-719-988-61	DIODE 1SS355TE-17		D633	8-719-948-45	DIODE ERA22-08TP3	
D309	8-719-069-54	DIODE UDZS-TE17-5.1B		D634	8-719-404-50	DIODE MA111-(K8).S0	
D311	8-719-988-61	DIODE 1SS355TE-17		D635	8-719-016-74	DIODE 1SS352-TPH3	
D312	8-719-988-61	DIODE 1SS355TE-17		D635	8-719-073-01	DIODE MA111-(K8).S0	
D313	8-719-988-61	DIODE 1SS355TE-17		D636	8-719-510-02	DIODE D1NS4-TA2	
D315	8-719-988-61	DIODE 1SS355TE-17		D637	8-719-109-96	DIODE RD6.8ES-T1B1	
D316	8-719-978-33	DIODE UDZS-TE17-6.8B		D638	8-719-200-82	DIODE 11ES2-TB5	
D320	8-719-069-60	DIODE UDZS-TE17-9.1B				<CONNECTOR>	
D321	8-719-069-60	DIODE UDZS-TE17-9.1B		DY1	* 1-580-798-11	CONNECTOR PIN (DY) 6P	
D504	8-719-936-85	DIODE RGP10GPKG23				<FERRITE BEAD>	
D505	8-719-988-61	DIODE 1SS355TE-17		FB501	1-410-397-21	FERRITE 1.1UH	
D506	8-719-921-20	DIODE 1SS119-25TD		FB502	1-410-397-21	FERRITE 1.1UH	
D507	8-719-988-61	DIODE 1SS355TE-17		FB600	1-410-397-21	FERRITE 1.1UH	
D508	8-719-988-61	DIODE 1SS355TE-17		FB601	1-410-397-21	FERRITE 1.1UH	
D509	1-216-073-61	RES-CHIP 10G	5% 1/10W	FB602	1-410-397-21	FERRITE 1.1UH	
D510	8-719-988-61	DIODE 1SS355TE-17		FB603	1-410-397-21	FERRITE 1.1UH	
D511	8-719-988-61	DIODE 1SS355TE-17		FB604	1-412-911-31	FERRITE 0UH	
D512	8-719-988-61	DIODE 1SS355TE-17		FB605	1-412-911-31	FERRITE 0UH	
D513	8-719-908-03	DIODE GP08DPKG23		FB606	1-412-911-31	FERRITE 0UH	
D517	8-719-312-71	DIODE RS3FS		FB607	1-410-397-21	FERRITE 1.1UH	
D518	8-719-074-35	DIODE RU4AM-T4		FB608	1-412-911-31	FERRITE 0UH	
D519	8-719-312-71	DIODE RS3FS		FB611	1-410-397-21	FERRITE 1.1UH	
D520	1-216-295-61	SHORT CHIP 0		FB612	1-410-397-21	FERRITE 1.1UH	
D521	8-719-936-85	DIODE RGP10GPKG23		FB613	1-410-397-21	FERRITE 1.1UH	
D522	8-719-936-85	DIODE RGP10GPKG23		FB615	1-410-397-21	FERRITE 1.1UH	
D523	8-719-936-85	DIODE RGP10GPKG23				<IC>	
D527	8-719-908-03	DIODE GP08DPKG23		IC001	8-752-905-64	IC CXP86461-621S	
D528	8-719-908-03	DIODE GP08DPKG23		IC002	8-759-371-21	IC MM1319AFBE	
D531	8-719-988-61	DIODE 1SS355TE-17		IC003	8-759-527-71	IC M24C08-BN6	
D532	8-719-988-61	DIODE 1SS355TE-17		IC301	8-752-090-41	IC CXA2139S	
D534	1-216-295-61	SHORT CHIP 0		IC502	8-759-700-07	IC NJM2903M-TE2	
D600	8-719-921-20	DIODE 1SS119-25TD		IC503	8-759-980-58	IC TDA8172	
D602	8-719-921-20	DIODE 1SS119-25TD		IC601	8-749-014-48	IC STR-F6656	
D603	8-719-150-92	DIODE RD33ES-T1B2		IC602	8-749-920-61	IC SE-135N	
D604	8-719-028-72	DIODE RGP02-17PKG23		IC603	8-759-701-59	IC L7809CV	
D605	8-719-510-27	DIODE D3SB60		IC604	8-759-231-53	IC L7805CV	
D606	8-719-108-18	DIODE TF541M				<CHIP CONDUCTOR>	
D607	8-719-404-50	DIODE MA111-TX		JR001	1-216-295-61	SHORT CHIP 0	
D608	8-719-110-53	DIODE RD20ES-T1B2		JR002	1-216-295-61	SHORT CHIP 0	
D609	8-719-075-79	DIODE BYV26E/23					
D610	8-719-210-21	DIODE 11EQS04-NTA1B					
D611	8-719-073-86	DIODE AU-01Z-V1					
D613	8-719-073-86	DIODE AU-01Z-V1					
D614	8-719-073-86	DIODE AU-01Z-V1					

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

A

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
JR004	1-216-295-61	SHORT CHIP	0	Q305	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L	
JR005	1-216-295-61	SHORT CHIP	0	Q306	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L	
JR006	1-216-295-61	SHORT CHIP	0				
JR007	1-216-295-61	SHORT CHIP	0	Q307	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
JR008	1-216-295-61	SHORT CHIP	0	Q308	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L	
JR010	1-216-295-61	SHORT CHIP	0	Q312	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L	
JR012	1-216-295-61	SHORT CHIP	0	Q313	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
JR014	1-216-295-61	SHORT CHIP	0	Q315	8-729-421-17	TRANSISTOR UN2213-TX	
JR015	1-216-295-61	SHORT CHIP	0	Q503	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
JR016	1-216-295-61	SHORT CHIP	0	Q505	8-729-931-45	TRANSISTOR IRF614	
JR102	1-216-295-61	SHORT CHIP	0	Q506	8-729-119-80	TRANSISTOR 2SC2688-LK	
JR109	1-216-295-61	SHORT CHIP	0	Q507	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L	
JR301	1-216-295-61	SHORT CHIP	0	Q509	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
JR303	1-216-295-61	SHORT CHIP	0	Q511	8-729-048-07	TRANSISTOR 2SD2578-CA	
JR500	1-216-295-61	SHORT CHIP	0	Q600	8-729-139-96	TRANSISTOR 2SC2785TP-HFE	
JR501	1-216-295-61	SHORT CHIP	0	Q601	8-729-023-22	TRANSISTOR 2SD2114KT146	
JR503	1-216-295-61	SHORT CHIP	0	Q602	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
JR600	1-216-295-61	SHORT CHIP	0	Q603	8-729-424-11	TRANSISTOR UN2111-TX	
		<COIL>		Q604	8-729-208-12	TRANSISTOR 2SA1091R-TPE2	
L002	1-414-856-11	INDUCTOR	10UH	Q605	8-729-044-30	TRANSISTOR 2SK2845-LB102	
L003	1-414-180-11	INDUCTOR	3.3UH	Q606	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
L005	1-414-233-22	INDUCTOR CHIP	0UH	Q607	8-729-922-37	TRANSISTOR 2SD2144S-TP-UVW	
L102	1-414-856-11	INDUCTOR	10UH	Q608	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L	
L103	1-414-856-11	INDUCTOR	10UH			<RESISTOR>	
L104	1-414-856-11	INDUCTOR	10UH	R001	1-414-233-22	INDUCTOR CHIP	0UH
L105	1-414-856-11	INDUCTOR	10UH	R002	1-216-025-61	RES-CHIP	100 5% 1/10W
L301	1-414-189-31	INDUCTOR	100UH	R003	1-216-073-61	RES-CHIP	10G 5% 1/10W
L302	1-414-185-41	INDUCTOR	22UH	R004	1-216-025-61	RES-CHIP	100 5% 1/10W
L501	1-412-525-31	INDUCTOR	10UH	R005	1-216-025-61	RES-CHIP	100 5% 1/10W
L502	1-422-613-11	COIL, AIR CORE		R008	1-216-065-61	RES-CHIP	4.7K 5% 1/10W
L503	1-412-525-31	INDUCTOR	10UH	R010	1-216-065-61	RES-CHIP	4.7K 5% 1/10W
L504	1-412-525-31	INDUCTOR	10UH	R011	1-216-065-61	RES-CHIP	4.7K 5% 1/10W
L507	1-459-111-00	INDUCTOR	10MH	R012	1-216-065-61	RES-CHIP	4.7K 5% 1/10W
L511	1-406-978-11	INDUCTOR	150UH	R013	1-216-065-61	RES-CHIP	4.7K 5% 1/10W
L512	1-412-549-31	INDUCTOR	1MH	R014	1-216-025-61	RES-CHIP	100 5% 1/10W
L513	1-412-549-31	INDUCTOR	1MH	R015	1-216-025-61	RES-CHIP	100 5% 1/10W
L515	1-459-104-00	COIL, WITH CORE		R018	1-216-033-61	RES-CHIP	220 5% 1/10W
L518	1-414-187-11	INDUCTOR	47UH	R019	1-216-073-61	RES-CHIP	10G 5% 1/10W
L601	1-412-527-11	INDUCTOR	15UH	R021	1-216-073-61	RES-CHIP	10G 5% 1/10W
L905	1-414-856-11	INDUCTOR	10UH	R022	1-216-025-61	RES-CHIP	100 5% 1/10W
		<PHOTO COUPLER>		R023	1-216-049-61	RES-CHIP	1K 5% 1/10W
PH600 $\triangle$	8-749-924-35	PHOTO COUPLER ON3171-R		R024	1-216-063-61	RES-CHIP	3.9K 5% 1/10W
		<TRANSISTOR>		R025	1-216-063-61	RES-CHIP	3.9K 5% 1/10W
Q001	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L		R026	1-216-063-61	RES-CHIP	3.9K 5% 1/10W
Q002	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L		R027	1-216-049-61	RES-CHIP	1K 5% 1/10W
Q003	8-729-424-11	TRANSISTOR UN2111-TX		R029	1-216-049-61	RES-CHIP	1K 5% 1/10W
Q004	8-729-421-20	TRANSISTOR UN2211-TX		R031	1-216-049-61	RES-CHIP	1K 5% 1/10W
Q101	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L		R032	1-216-025-61	RES-CHIP	100 5% 1/10W
Q301	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L		R034	1-216-049-61	RES-CHIP	1K 5% 1/10W
Q302	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L		R035	1-216-025-61	RES-CHIP	100 5% 1/10W
Q303	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L		R036	1-216-025-61	RES-CHIP	100 5% 1/10W
				R037	1-216-025-61	RES-CHIP	100 5% 1/10W
				R038	1-216-049-61	RES-CHIP	1K 5% 1/10W
				R040	1-216-025-61	RES-CHIP	100 5% 1/10W
				R041	1-216-025-61	RES-CHIP	100 5% 1/10W
				R042	1-216-295-61	SHORT CHIP	0
				R043	1-216-049-61	RES-CHIP	1K 5% 1/10W

A

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R044	1-216-025-61	RES-CHIP	100	5%	1/10W	R345	1-216-081-61	RES-CHIP	22K	5%	1/10W
R045	1-414-233-22	INDUCTOR CHIP	0UH			R346	1-216-051-61	RES-CHIP	1.2K	5%	1/10W
R046	1-216-049-61	RES-CHIP	1K	5%	1/10W	R347	1-216-051-61	RES-CHIP	1.2K	5%	1/10W
R047	1-414-233-22	INDUCTOR CHIP	0UH			R348	1-208-806-11	METAL CHIP	10K	0.5%	1/10W
R048	1-216-073-61	RES-CHIP	10G	5%	1/10W	R349	1-216-073-61	RES-CHIP	10G	5%	1/10W
R049	1-216-073-61	RES-CHIP	10G	5%	1/10W	R350	1-216-061-61	RES-CHIP	3.3G	5%	1/10W
R050	1-216-073-61	RES-CHIP	10G	5%	1/10W	R351	1-216-053-61	RES-CHIP	1.5K	5%	1/10W
R052	1-216-053-61	RES-CHIP	1.5K	5%	1/10W	R354	1-216-057-61	RES-CHIP	2.2K	5%	1/10W
R053	1-216-049-61	RES-CHIP	1K	5%	1/10W	R355	1-216-057-61	RES-CHIP	2.2K	5%	1/10W
R054	1-216-049-61	RES-CHIP	1K	5%	1/10W	R356	1-216-057-61	RES-CHIP	2.2K	5%	1/10W
R055	1-216-073-61	RES-CHIP	10G	5%	1/10W	R357	1-216-079-00	METAL CHIP	18K	5%	1/10W
R056	1-216-073-61	RES-CHIP	10G	5%	1/10W	R358	1-216-049-61	RES-CHIP	1K	5%	1/10W
R061	1-216-295-61	SHORT CHIP	0			R359	1-216-033-61	RES-CHIP	220	5%	1/10W
R062	1-216-041-61	RES-CHIP	470	5%	1/10W	R360	1-216-033-61	RES-CHIP	220	5%	1/10W
R063	1-216-041-61	RES-CHIP	470	5%	1/10W	R361	1-216-073-61	RES-CHIP	10G	5%	1/10W
R064	1-216-041-61	RES-CHIP	470	5%	1/10W	R362	1-216-075-61	RES-CHIP	12K	5%	1/10W
R065	1-216-041-61	RES-CHIP	470	5%	1/10W	R363	1-216-079-00	METAL CHIP	18K	5%	1/10W
R066	1-216-049-61	RES-CHIP	1K	5%	1/10W	R364	1-216-295-61	SHORT CHIP	0		
R067	1-216-049-61	RES-CHIP	1K	5%	1/10W	R365	1-216-033-61	RES-CHIP	220	5%	1/10W
R105	1-216-295-61	SHORT CHIP	0			R366	1-216-073-61	RES-CHIP	10G	5%	1/10W
R109	1-216-041-61	RES-CHIP	470	5%	1/10W	R367	1-216-073-61	RES-CHIP	10G	5%	1/10W
R111	1-216-025-61	RES-CHIP	100	5%	1/10W	R368	1-216-073-61	RES-CHIP	10G	5%	1/10W
R112	1-216-025-61	RES-CHIP	100	5%	1/10W	R370	1-216-033-61	RES-CHIP	220	5%	1/10W
R113	1-216-025-61	RES-CHIP	100	5%	1/10W	R373	1-216-025-61	RES-CHIP	100	5%	1/10W
R225	1-216-033-61	RES-CHIP	220	5%	1/10W	R376	1-216-081-61	RES-CHIP	22K	5%	1/10W
R226	1-216-033-61	RES-CHIP	220	5%	1/10W	R377	1-216-121-61	RES-CHIP	1M	5%	1/10W
R227	1-216-033-61	RES-CHIP	220	5%	1/10W	R378	1-216-031-61	RES-CHIP	180	5%	1/10W
R237	1-216-295-61	SHORT CHIP	0			R500	1-220-958-91	RES, METAL FILM	1K		
R301	1-216-113-61	RES-CHIP	470K	5%	1/10W	R501	1-216-049-61	RES-CHIP	1K	5%	1/10W
R302	1-216-295-61	SHORT CHIP	0			R505	1-216-105-61	METAL CHIP	220K	5%	1/10W
R303	1-216-049-61	RES-CHIP	1K	5%	1/10W	R506	1-216-089-61	RES-CHIP	47K		(2012)
R304	1-216-073-61	RES-CHIP	10G	5%	1/10W	R507	1-249-389-11	CARBON	4.7	5%	1/4W
R306	1-216-085-00	METAL CHIP	33K	5%	1/10W	R508	1-216-473-11	METAL OXIDE	56	5%	3W
R308	1-216-025-61	RES-CHIP	100	5%	1/10W	R509	1-215-910-00	METAL OXIDE	68	5%	3W
R309	1-216-025-61	RES-CHIP	100	5%	1/10W	R510	1-215-884-11	METAL OXIDE	47	5%	2W
R310	1-216-025-61	RES-CHIP	100	5%	1/10W	R511	1-215-910-00	METAL OXIDE	68	5%	3W
R311	1-216-017-61	RES-CHIP	47	5%	1/10W	R515	1-215-913-11	METAL OXIDE	220	5%	3W
R312	1-216-041-61	RES-CHIP	470	5%	1/10W	R516	1-216-081-61	RES-CHIP	22K	5%	1/10W
R313	1-216-053-61	RES-CHIP	1.5K	5%	1/10W	R518	1-220-948-91	METAL	100	5%	1/2W
R314	1-216-043-61	RES-CHIP	560	5%	1/10W	R519	1-215-912-11	METAL OXIDE	150	5%	3W
R316	1-216-053-61	RES-CHIP	1.5K	5%	1/10W	R520	1-215-445-00	METAL	10K	1%	1/4W
R317	1-216-077-61	RES-CHIP	15K		(2012)	R522	1-208-806-11	METAL CHIP	10K	0.5%	1/10W
R318	1-216-051-61	RES-CHIP	1.2K	5%	1/10W	R523	1-220-952-91	METAL MELF	330	5%	1/2W
R319	1-216-025-61	RES-CHIP	100	5%	1/10W	R525	1-208-854-11	METAL CHIP	1M	0.5%	1/10W
R320	1-216-065-61	RES-CHIP	4.7K	5%	1/10W	R526	1-208-804-11	METAL CHIP	8.2K	0.5%	1/10W
R321	1-216-073-61	RES-CHIP	10G	5%	1/10W	R527	1-216-001-61	RES-CHIP	10	5%	1/10W
R322	1-216-033-61	RES-CHIP	220	5%	1/10W	R528	1-208-814-91	METAL CHIP	22K	0.5%	1/10W
R326	1-216-029-61	RES-CHIP	150	5%	1/10W	R529	1-216-635-11	METAL CHIP	220	0.5%	1/10W
R327	1-216-033-61	RES-CHIP	220	5%	1/10W	R531	1-220-963-91	METAL MELF	3.3K	5%	1/2W
R331	1-216-295-61	SHORT CHIP	0			R533	1-220-958-91	RES, METAL FILM	1K		
R332	1-216-033-61	RES-CHIP	220	5%	1/10W	R534	1-216-361-00	METAL OXIDE	0.22	5%	2W
R333	1-216-083-61	RES-CHIP	27K	5%	1/10W	R535	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R334	1-216-125-00	METAL CHIP	1.5M	5%	1/10W	R536	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R335	1-216-045-00	METAL CHIP	680	5%	1/10W	R537	1-208-814-91	METAL CHIP	22K	0.5%	1/10W
R338	1-216-037-61	RES-CHIP	330	5%	1/10W	R540	1-216-065-61	RES-CHIP	4.7K	5%	1/10W
R339	1-216-033-61	RES-CHIP	220	5%	1/10W	R541	1-216-065-61	RES-CHIP	4.7K	5%	1/10W
R340	1-216-025-61	RES-CHIP	100	5%	1/10W	R542	1-216-295-61	SHORT CHIP	0		

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

A

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R543	1-249-426-11	CARBON	5.6K	5%	1/4W		
R544	1-215-917-11	METAL OXIDE	1K	5%	3W		(2012)
R545	1-216-077-61	RES-CHIP	15K				
R546	1-216-077-61	RES-CHIP	15K				(2012)
R547	1-216-085-00	METAL CHIP	33K	5%	1/10W		
R549	1-215-453-00	METAL	22K	1%	1/4W		
R550	1-216-097-61	RES-CHIP	100K	5%	1/10W		
R551	1-220-961-91	METAL CHIP	2.2K	5%	1/2W		
R552	1-216-057-61	RES-CHIP	2.2K	5%	1/10W		
R553	1-215-453-00	METAL	22K	1%	1/4W		
R554	1-215-457-00	METAL	33K	1%	1/4W		
R556	1-215-437-00	METAL	4.7K	1%	1/4W		
R558	1-220-963-91	METAL MELF	3.3K	5%	1/2W		
R559	1-220-969-91	METAL CHIP	10K	5%	1/2W		
R560	1-216-073-61	RES-CHIP	10G	5%	1/10W		
R562	1-249-401-11	CARBON	47	5%	1/4W		
R565	1-216-073-61	RES-CHIP	10G	5%	1/10W		
R567	1-216-105-61	METAL CHIP	220K	5%	1/10W		
R568	1-249-383-11	CARBON	1.5	5%	1/4W		
R570	1-216-069-61	RES-CHIP	6.8K	5%	1/10W		
R571	1-215-443-00	METAL	8.2K	1%	1/4W		
R573	1-216-089-61	RES, CHIP 47K					(2012)
R577	1-215-913-11	METAL OXIDE	220	5%	3W		
R578	1-216-369-00	METAL OXIDE	1	5%	2W		
R579	1-216-097-61	RES-CHIP	100K	5%	1/10W		
R580	1-208-830-11	METAL CHIP	100K	0.5%	1/10W		
R581	1-208-798-11	METAL CHIP	4.7K	0.5%	1/10W		
R582	1-216-113-61	RES-CHIP	470K	5%	1/10W		
R584	1-216-081-61	RES-CHIP	22K	5%	1/10W		
R587	1-216-097-61	RES-CHIP	100K	5%	1/10W		
R588	1-215-888-00	METAL OXIDE	220	5%	2W		
R589	1-215-888-00	METAL OXIDE	220	5%	2W		
R590	1-215-465-00	METAL	68K	1%	1/4W		
R591	1-260-288-11	CARBON	0.47	5%	1/2W		
R593	1-260-288-11	CARBON	0.47	5%	1/2W		
R594	1-260-288-11	CARBON	0.47	5%	1/2W		
R596	1-215-917-11	METAL OXIDE	1K	5%	3W		
R597	1-247-750-11	CARBON	680	5%	1/2W		
R598	1-220-976-91	METAL MELF	56K	5%	1/2W		
R599	1-249-389-11	CARBON	4.7	5%	1/4W		
R600	1-220-976-91	METAL MELF	56K	5%	1/2W		
R601	1-249-420-11	CARBON	1.8K	5%	1/4W		
R602	1-249-389-11	CARBON	4.7	5%	1/4W		
R603	1-215-485-00	METAL	470K	1%	1/4W		
R604	1-216-097-61	RES-CHIP	100K	5%	1/10W		
R607	1-220-965-91	METAL CHIP	4.7K	5%	1/2W		
R608	1-240-205-91	CARBON	22M	5%	1/2W		
R609	1-216-057-61	RES-CHIP	2.2K	5%	1/10W		
R610	1-216-073-61	RES-CHIP	10G	5%	1/10W		
R611	1-216-089-61	RES-CHIP	47K		(2012)		
R612	1-216-045-00	METAL CHIP	680	5%	1/10W		
R614	1-216-041-61	RES-CHIP	470	5%	1/10W		
R615	1-216-369-00	METAL OXIDE	1	5%	2W		
R616	1-260-302-51	CARBON	6.8	5%	1/2W		
R617	1-247-791-91	CARBON	22	5%	1/4W		
R619	1-260-128-11	CARBON	270K	5%	1/2W		
R621	1-215-864-00	METAL OXIDE	150	5%	1W		
R623	1-216-095-61	RES-CHIP	82K	5%	1/10W		
R624	1-216-089-61	RES-CHIP	47K				(2012)
R626	1-216-049-61	RES-CHIP	1K	5%	1/10W		
R627	1-240-251-11	CMT-MELF	6.8	5%	10W		
R629	1-247-747-11	CARBON	470	5%	1/2W		
R630	1-249-429-11	CARBON	10K	5%	1/4W		
R631	1-216-089-61	RES, CHIP 47K					(2012)
R632	1-202-933-61	FUSIBLE	0.1	10%	1/2W		
R634	$\triangle$ 1-218-265-11	METAL	8.2M	5%	1W		
R635	1-216-492-11	METAL OXIDE	82K	5%	3W		
R636	1-215-924-00	METAL OXIDE	15K	5%	3W		
R637	1-216-492-11	METAL OXIDE	82K	5%	3W		
R639	1-216-361-21	METAL OXIDE	0.22	5%	2W		
R640	1-220-956-91	METAL MELF	680	5%	1/2W		
R641	1-216-361-21	METAL OXIDE	0.22	5%	2W		
R642	1-220-959-91	METAL MELF	1.5K	5%	1/2W		
R643	1-220-963-91	METAL MELF	3.3K	5%	1/2W		
R644	1-220-959-91	METAL MELF	1.5K	5%	1/2W		
R646	1-215-924-00	METAL OXIDE	15K	5%	3W		
R647	1-249-387-11	CARBON	3.3	5%	1/4W		
R648	1-216-057-61	RES-CHIP	2.2K	5%	1/10W		
R649	1-220-958-91	RES, METAL FILM 1K					
R650	1-215-882-00	METAL OXIDE	22	5%	2W		
R652	1-215-900-11	METAL OXIDE	22K	5%	2W		
R653	1-215-873-00	METAL OXIDE	4.7K	5%	1W		
R654	1-216-369-00	METAL OXIDE	1	5%	2W		
R656	1-220-958-91	RES, METAL FILM 1K					
R657	1-260-127-11	CARBON	220K	5%	1/2W		
R659	1-216-049-61	RES-CHIP	1K	5%	1/10W		
R660	1-216-073-61	RES-CHIP	10G	5%	1/10W		
R661	1-215-873-00	METAL OXIDE	4.7K	5%	1W		
R909	1-216-065-61	RES-CHIP	4.7K	5%	1/10W		
R910	1-216-065-61	RES-CHIP	4.7K	5%	1/10W		
		<RELAY>					
RY600	$\triangle$ 1-755-214-11	RELAY, AC POWER					
RY601	$\triangle$ 1-755-214-11	RELAY, AC POWER					
		<SWITCH>					
S501	1-572-707-11	SWITCH, LEVER					
S502	1-572-707-11	SWITCH, LEVER					
		<TRANSFORMER>					
T501	1-437-195-11	TRANSFORMER, HORIZONTAL DRIVE					
T503	$\triangle$ 1-453-284-11	TRANSFORMER ASSY FLYBACK (NX-4009/M314)					
T504	1-431-475-11	TRANSFORMER, HORIZONTAL LINEAR					
T505	1-426-981-11	TRANSFORMER, FERRITE (PMT)					
T601	1-424-505-11	TRANSFORMER, LINE FILTER					
T603	$\triangle$ 1-431-946-11	TRANSFORMER, CONVERTER					
T604	$\triangle$ 1-431-852-11	TRANSFORMER, CONVERTER (SRT)					
		<THERMISTOR>					
THP600	1-809-827-11	THERMISTOR, POSITIVE					



REF.NO.	PART NO.	DESCRIPTION	REMARK
		<TUNER>	
TU101	8-598-449-10	TUNER, FSS BTF-LG433	
		<CRYSTAL>	
X001	1-781-174-21	VIBRATOR, CERAMIC	
X301	1-781-134-21	VIBRATOR, CRYSTAL	
X302	1-781-132-21	VIBRATOR, CRYSTAL	
*****			
	* A-1131-417-A	B2 BOARD MOUNTED *****	
		<CONNECTOR>	
CN2302	* 1-766-952-11	CONNECTOR, BOARD TO BOARD 11P	
*****			
	* A-1136-131-A	B3 BOARD COMPLETE *****	
	4-382-854-11	SCREW (M3X10), P, SW (+)	
		<CAPACITOR>	
C1402	1-104-664-11	ELECT 47UF	20.00% 25V
C1404	1-216-295-61	SHORT CHIP 0	
C1405	1-104-664-11	ELECT 47UF	20.00% 25V
C1410	1-104-664-11	ELECT 47UF	20.00% 25V
C1411	1-216-295-61	SHORT CHIP 0	
C1413	1-126-935-11	ELECT 470UF	20.00% 16V
C1414	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1415	1-104-664-11	ELECT 47UF	20.00% 25V
C1416	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1418	1-163-031-11	CERAMIC CHIP 0.01UF	50V
C1422	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1423	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1425	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1426	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1428	1-104-665-11	ELECT 100UF	20.00% 25V
C1429	1-104-663-11	ELECT 33UF	20.00% 25V
C1431	1-163-038-00	CERAMIC CHIP 0.1UF	25V
C1433	1-104-664-11	ELECT 47UF	20.00% 16V
C1434	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1435	1-163-038-00	CERAMIC CHIP 0.1UF	25V
C1436	1-163-038-00	CERAMIC CHIP 0.1UF	25V
C1440	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1441	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1443	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1444	1-164-005-51	CERAMIC CHIP 470000PF	10% 25V
C1445	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1446	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1447	1-125-797-91	ELECT 10UF	20.00% 50V

REF.NO.	PART NO.	DESCRIPTION	REMARK
C1448	1-164-005-51	CERAMIC CHIP 470000PF	10% 25V
C1449	1-126-933-11	ELECT 100UF	20.00% 16V
C1459	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1460	1-163-133-00	CERAMIC CHIP 470PF	10% 50V
C1461	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C1462	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C3201	1-125-797-91	ELECT 10UF	20.00% 50V
C3202	1-136-169-00	MYLAR 0.22UF	5.00% 50V
C3203	1-115-339-51	CERAMIC CHIP 0.1UF	10.00% 50V
C3206	1-164-232-11	CERAMIC CHIP 0.01UF	10.00% 50V
C3207	1-164-489-51	CERAMIC CHIP 0.22UF	10.00% 16V
C3208	1-164-489-51	CERAMIC CHIP 0.22UF	10.00% 16V
C3209	1-163-017-00	CERAMIC CHIP 0.0047UF	10.00% 50V
C3210	1-125-797-91	ELECT 10UF	20.00% 50V
C3211	1-125-797-91	ELECT 10UF	20.00% 50V
C3212	1-125-797-91	ELECT 10UF	20.00% 50V
C3213	1-104-664-11	ELECT 47UF	20.00% 25V
C3214	1-104-664-11	ELECT 47UF	20.00% 25V
C3215	1-117-720-51	CERAMIC CHIP 4.7UF	10V
C3216	1-117-720-51	CERAMIC CHIP 4.7UF	10V
C3217	1-164-232-11	CERAMIC CHIP 0.01UF	10.00% 50V
C3218	1-163-017-00	CERAMIC CHIP 0.0047UF	10.00% 50V
C3219	1-163-017-00	CERAMIC CHIP 0.0047UF	10.00% 50V
C3220	1-163-037-11	CERAMIC CHIP 0.022UF	10.00% 50V
C3221	1-163-037-11	CERAMIC CHIP 0.022UF	10.00% 50V
C3222	1-163-037-11	CERAMIC CHIP 0.022UF	10.00% 50V
C3223	1-163-037-11	CERAMIC CHIP 0.022UF	10.00% 50V
C3224	1-164-505-11	CERAMIC CHIP 2.2UF	16V
C3225	1-163-038-00	CERAMIC CHIP 0.1UF	25V
C3226	1-125-797-91	ELECT 10UF	20.00% 50V
C3227	1-164-505-11	CERAMIC CHIP 2.2UF	16V
C3228	1-107-698-11	ELECT 10UF	20.00% 25V
C3229	1-107-698-11	ELECT 10UF	20.00% 25V
C3238	1-164-005-51	CERAMIC CHIP 470000PF	10% 25V
C3239	1-136-169-00	MYLAR 0.22UF	5.00% 50V
C3240	1-115-339-51	CERAMIC CHIP 0.1UF	10.00% 50V
C3243	1-163-989-51	CERAMIC CHIP 0.033UF	10.00% 25V
C3244	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C3245	1-164-005-51	CERAMIC CHIP 470000PF	10% 25V
C3246	1-163-243-11	CERAMIC CHIP 47PF	5.00% 50V
C3247	1-126-963-11	ELECT 4.7UF	20.00% 50V
C3248	1-163-251-11	CERAMIC CHIP 100PF	5.00% 50V
C3249	1-164-505-11	CERAMIC CHIP 2.2UF	16V
C3250	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C3251	1-125-797-91	ELECT 10UF	20.00% 50V
C3252	1-163-251-11	CERAMIC CHIP 100PF	5.00% 50V
C3253	1-126-933-11	ELECT 100UF	20.00% 16V
C3254	1-164-505-11	CERAMIC CHIP 2.2UF	16V
C3255	1-163-243-11	CERAMIC CHIP 47PF	5.00% 50V
C3256	1-126-963-11	ELECT 4.7UF	20.00% 50V
C3257	1-164-346-51	CERAMIC CHIP 1UF	10% 16V
C3258	1-163-989-51	CERAMIC CHIP 0.033UF	10.00% 25V
C3259	1-126-963-11	ELECT 4.7UF	20.00% 50V
C3260	1-163-251-11	CERAMIC CHIP 100PF	5.00% 50V
C3262	1-104-664-11	ELECT 47UF	20.00% 16V
C3264	1-163-251-11	CERAMIC CHIP 100PF	5.00% 50V
C3265	1-125-797-91	ELECT 10UF	20.00% 50V

B3

REF.NO.	PART NO.	DESCRIPTION	REMARK		REF.NO.	PART NO.	DESCRIPTION	REMARK
C3266	1-125-797-91	ELECT	10UF	20.00% 50V			<DIODE>	
C3268	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V				
C3269	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V				
C3270	1-164-690-51	CERAMIC CHIP	0.0022UF	5.00% 50V				
C3271	1-164-690-51	CERAMIC CHIP	0.0022UF	5.00% 50V				
C3272	1-126-965-11	ELECT	22UF	20.00% 50V	D1401	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3273	1-115-339-51	CERAMIC CHIP	0.1UF	10.00% 50V	D1402	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3274	1-125-797-91	ELECT	10UF	20.00% 50V	D1403	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3276	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V	D1404	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3277	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V	D1405	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3278	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V	D1406	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3279	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V	D1407	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3280	1-115-419-11	CERAMIC CHIP	3300PF	5.00% 25V	D1408	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3281	1-163-037-11	CERAMIC CHIP	0.022UF	10.00% 50V	D1409	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3282	1-125-797-91	ELECT	10UF	20.00% 50V	D1410	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3283	1-125-797-91	ELECT	10UF	20.00% 50V	D1411	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3284	1-115-339-51	CERAMIC CHIP	0.1UF	10.00% 50V	D1412	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3285	1-125-797-91	ELECT	10UF	20.00% 50V	D1415	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3286	1-125-797-91	ELECT	10UF	20.00% 50V	D1416	8-719-069-60	DIODE UDZS-TE17-9.1B	
C3287	1-125-797-91	ELECT	10UF	20.00% 50V	D3201	8-719-988-61	DIODE 1SS355TE-17	
C3288	1-163-037-11	CERAMIC CHIP	0.022UF	10.00% 50V	D3203	8-719-988-61	DIODE 1SS355TE-17	
C3289	1-115-419-11	CERAMIC CHIP	3300PF	5.00% 25V	D6211	8-719-404-50	DIODE MA111-TX	
C3290	1-164-505-11	CERAMIC CHIP	2.2UF	16V	D6212	8-719-404-50	DIODE MA111-TX	
C3291	1-164-505-11	CERAMIC CHIP	2.2UF	16V			<IC>	
C6200	1-216-295-61	SHORT CHIP	0		IC1401	8-752-068-46	IC CXA1855S	
C6202	1-126-953-11	ELECT	2200UF	20.00% 35V	IC1404	8-759-701-59	IC L7809CV	
C6203	1-164-232-11	CERAMIC CHIP	0.01UF	10.00% 50V	IC3200	8-759-103-37	IC UPC4558G2-T2	
C6204	1-128-550-11	ELECT	2200UF	20.00% 50V	IC3201	8-759-553-44	IC NJM2187L	
C6205	1-130-495-00	MYLAR	0.1UF	5.00% 50V	IC3202	8-759-100-96	IC UPC4558G2-T2	
C6206	1-128-550-11	ELECT	2200UF	20.00% 50V	IC3203	8-759-711-10	IC NJU4066BM-T2	
C6209	1-130-495-00	MYLAR	0.1UF	5.00% 50V	IC3204	8-759-100-96	IC NJM4558M-TE2	
C6210	1-126-924-11	ELECT	330UF	20.00% 10V	IC3205	8-752-057-18	IC CXA1315P	
C6211	1-126-924-11	ELECT	330UF	20.00% 10V	IC3206	8-759-496-02	IC NJM2150D	
C6212	1-104-664-11	ELECT	47UF	20.00% 25V	IC3207	8-759-273-12	IC TDA7315D013TR	
C6213	1-125-797-91	ELECT	10UF	20.00% 50V	IC6200	8-759-168-24	IC TA8200AH	
C6217	1-164-004-51	CERAMIC CHIP	0.1UF	10.00% 25V				
C6220	1-164-505-11	CERAMIC CHIP	2.2UF	16V			<JACK>	
C6222	1-164-505-11	CERAMIC CHIP	2.2UF	16V	J1401	1-784-646-11	TERMINAL, S	
C6223	1-125-799-91	ELECT	1UF	20.00% 63V	J1402	1-778-388-11	JACK BLOCK, PIN 9P	
C6241	1-125-797-91	ELECT	10UF	20.00% 50V				
C6244	1-164-161-11	CERAMIC CHIP	0.0022UF	10.00% 50V			<CHIP CONDUCTOR>	
C6245	1-164-161-11	CERAMIC CHIP	0.0022UF	10.00% 50V	JR1405	1-216-295-61	SHORT CHIP	0
C6249	1-216-295-61	SHORT CHIP	0		JR1406	1-216-295-61	SHORT CHIP	0
		<CONNECTOR>			JR1407	1-216-295-61	SHORT CHIP	0
CN1400 *	1-564-512-11	PLUG, CONNECTOR 9P			JR1408	1-216-295-61	SHORT CHIP	0
CN1401 *	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P			JR3200	1-216-295-61	SHORT CHIP	0
CN1403 *	1-564-506-11	PLUG, CONNECTOR 3P			JR3201	1-216-295-61	SHORT CHIP	0
CN1405 *	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P			JR3202	1-216-295-61	SHORT CHIP	0
CN1407 *	1-779-891-11	CONNECTOR, BOARD TO BOARD 8P			JR3203	1-216-295-61	SHORT CHIP	0
CN6200 *	1-564-507-11	PLUG, CONNECTOR 4P			JR3204	1-216-295-61	SHORT CHIP	0
CN6204 *	1-564-509-11	PLUG, CONNECTOR 6P			JR3207	1-216-295-61	SHORT CHIP	0
CN6206 *	1-564-508-11	PLUG, CONNECTOR 5P			JR3208	1-216-295-61	SHORT CHIP	0
					JR3209	1-216-295-61	SHORT CHIP	0
					JR6200	1-216-295-61	SHORT CHIP	0
					JR6202	1-216-295-61	SHORT CHIP	0
					JR6203	1-216-295-61	SHORT CHIP	0



B3

REF.NO.	PART NO.	DESCRIPTION	REMARK				REF.NO.	PART NO.	DESCRIPTION	REMARK			
JR6204	1-216-295-61	SHORT CHIP	0				R1433	1-216-025-61	RES-CHIP	100	5%	1/10W	
		<COIL>					R1435	1-216-022-00	METAL CHIP	75	5%	1/10W	
L1404	1-412-537-31	INDUCTOR	100UH				R1436	1-216-025-61	RES-CHIP	100	5%	1/10W	
L3202	1-414-856-11	INDUCTOR	10UH				R1437	1-216-022-00	METAL CHIP	75	5%	1/10W	
		<TRANSISTOR>					R1438	1-216-025-61	RES-CHIP	100	5%	1/10W	
Q1402	8-729-230-47	TRANSISTOR 2SA1162-YG-TE85L					R1441	1-216-025-61	RES-CHIP	100	5%	1/10W	
Q1403	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L					R1442	1-216-049-61	RES-CHIP	1K	5%	1/10W	
Q1404	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L					R1443	1-216-049-61	RES-CHIP	1K	5%	1/10W	
Q3201	8-729-224-62	TRANSISTOR 2SK246GR-TPE2					R1445	1-216-025-61	RES-CHIP	100	5%	1/10W	
Q3202	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L					R1446	1-216-105-61	METAL CHIP	220K	5%	1/10W	
Q3203	8-729-230-50	TRANSISTOR 2SC2712-YG-TE85L					R1447	1-216-025-61	RES-CHIP	100	5%	1/10W	
Q3204	8-729-224-62	TRANSISTOR 2SK246GR-TPE2					R1449	1-216-073-61	RES-CHIP	10G	5%	1/10W	
Q6201	8-729-421-17	TRANSISTOR UN2213-TX					R1450	1-216-073-61	RES-CHIP	10G	5%	1/10W	
Q6203	8-729-421-17	TRANSISTOR UN2213-TX					R1451	1-216-073-61	RES-CHIP	10G	5%	1/10W	
Q6204	8-729-421-17	TRANSISTOR UN2213-TX					R1452	1-216-295-61	SHORT CHIP	0			
Q6208	8-729-421-17	TRANSISTOR UN2213-TX					R1453	1-216-025-61	RES-CHIP	100	5%	1/10W	
		<RESISTOR>					R1455	1-216-073-61	RES-CHIP	10G	5%	1/10W	
R1403	1-216-033-61	RES-CHIP	220	5%	1/10W		R1456	1-216-113-61	RES-CHIP	470K	5%	1/10W	
R1404	1-216-295-61	SHORT CHIP	0				R1457	1-216-073-61	RES-CHIP	10G	5%	1/10W	
R1406	1-216-017-61	RES-CHIP	47	5%	1/10W		R1458	1-216-073-61	RES-CHIP	10G	5%	1/10W	
R1407	1-216-033-61	RES-CHIP	220	5%	1/10W		R1459	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1408	1-216-031-61	RES-CHIP	180	5%	1/10W		R1460	1-216-033-61	RES-CHIP	220	5%	1/10W	
R1409	1-216-105-61	METAL CHIP	220K	5%	1/10W		R1461	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1410	1-216-105-61	METAL CHIP	220K	5%	1/10W		R1463	1-216-073-61	RES-CHIP	10G	5%	1/10W	
R1411	1-216-295-61	SHORT CHIP	0				R1464	1-216-113-61	RES-CHIP	470K	5%	1/10W	
R1412	1-216-295-61	SHORT CHIP	0				R1465	1-216-113-61	RES-CHIP	470K	5%	1/10W	
R1414	1-216-025-61	RES-CHIP	100	5%	1/10W		R1466	1-216-033-61	RES-CHIP	220	5%	1/10W	
R1417	1-216-025-61	RES-CHIP	100	5%	1/10W		R1467	1-216-057-61	RES-CHIP	2.2K	5%	1/10W	
R1418	1-216-025-61	RES-CHIP	100	5%	1/10W		R1468	1-216-093-11	METAL CHIP	68K	5%	1/10W	
R1426	1-216-025-61	RES-CHIP	100	5%	1/10W		R1469	1-216-105-61	METAL CHIP	220K	5%	1/10W	
R1428	1-216-025-61	RES-CHIP	100	5%	1/10W		R1470	1-216-105-61	METAL CHIP	220K	5%	1/10W	
R1429	1-216-295-61	SHORT CHIP	0				R1471	1-216-022-00	METAL CHIP	75	5%	1/10W	
R1430	1-216-025-61	RES-CHIP	100	5%	1/10W		R1472	1-216-033-61	RES-CHIP	220	5%	1/10W	
R1403	1-216-033-61	RES-CHIP	220	5%	1/10W		R1473	1-216-033-61	RES-CHIP	220	5%	1/10W	
R1404	1-216-295-61	SHORT CHIP	0				R1477	1-216-047-00	METAL CHIP	820	5%	1/10W	
R1406	1-216-017-61	RES-CHIP	47	5%	1/10W		R1478	1-216-051-61	RES-CHIP	1.2K	5%	1/10W	
R1407	1-216-033-61	RES-CHIP	220	5%	1/10W		R1479	1-216-105-61	METAL CHIP	220K	5%	1/10W	
R1408	1-216-031-61	RES-CHIP	180	5%	1/10W		R1480	1-216-105-61	METAL CHIP	220K	5%	1/10W	
R1409	1-216-105-61	METAL CHIP	220K	5%	1/10W		R1481	1-216-022-00	METAL CHIP	75	5%	1/10W	
R1410	1-216-105-61	METAL CHIP	220K	5%	1/10W		R1482	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1411	1-216-295-61	SHORT CHIP	0				R1483	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1412	1-216-295-61	SHORT CHIP	0				R1484	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1414	1-216-025-61	RES-CHIP	100	5%	1/10W		R1485	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1417	1-216-025-61	RES-CHIP	100	5%	1/10W		R1486	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	
R1418	1-216-025-61	RES-CHIP	100	5%	1/10W		R1490	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1426	1-216-025-61	RES-CHIP	100	5%	1/10W		R1491	1-216-025-61	RES-CHIP	100	5%	1/10W	
R1428	1-216-025-61	RES-CHIP	100	5%	1/10W		R1492	1-216-021-61	RES-CHIP	68	5%	1/10W	
R1429	1-216-295-61	SHORT CHIP	0				R1493	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	
R1430	1-216-025-61	RES-CHIP	100	5%	1/10W		R1496	1-216-041-61	RES-CHIP	470	5%	1/10W	
R1431	1-216-025-61	RES-CHIP	100	5%	1/10W		R1497	1-216-041-61	RES-CHIP	470	5%	1/10W	
							R1498	1-216-025-61	RES-CHIP	100	5%	1/10W	
							R1499	1-216-025-61	RES-CHIP	100	5%	1/10W	
							R1500	1-216-025-61	RES-CHIP	100	5%	1/10W	
							R3200	1-216-121-61	RES-CHIP	1M	5%	1/10W	
							R3201	1-216-121-61	RES-CHIP	1M	5%	1/10W	
							R3202	1-216-097-61	RES-CHIP	100K	5%	1/10W	
							R3203	1-216-121-61	RES-CHIP	1M	5%	1/10W	

B3

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R3204	1-216-061-61	RES-CHIP	3.3G	5%	1/10W	R3262	1-216-115-00	METAL CHIP	560K	5%	1/10W
R3205	1-216-069-61	RES-CHIP	6.8K	5%	1/10W	R3263	1-216-093-11	METAL CHIP	68K	5%	1/10W
R3206	1-216-039-61	RES-CHIP	390	5%	1/10W						
R3207	1-216-073-61	RES-CHIP	10G	5%	1/10W	R3264	1-216-053-61	RES-CHIP	1.5K	5%	1/10W
R3208	1-216-053-61	RES-CHIP	1.5K	5%	1/10W	R3266	1-216-295-61	SHORT CHIP	0		
						R3267	1-216-049-61	RES-CHIP	1K	5%	1/10W
R3209	1-216-069-61	RES-CHIP	6.8K	5%	1/10W	R3268	1-216-049-61	RES-CHIP	1K	5%	1/10W
R3210	1-216-053-61	RES-CHIP	1.5K	5%	1/10W	R3269	1-216-057-61	RES-CHIP	2.2K	5%	1/10W
R3211	1-216-069-61	RES-CHIP	6.8K	5%	1/10W						
R3212	1-216-049-61	RES-CHIP	1K	5%	1/10W	R3270	1-216-295-61	SHORT CHIP	0		
R3213	1-216-091-61	RES-CHIP	56K	5%	1/10W	R3271	1-216-069-61	RES-CHIP	6.8K	5%	1/10W
						R3272	1-216-069-61	RES-CHIP	6.8K	5%	1/10W
R3214	1-216-295-61	SHORT CHIP	0			R3273	1-216-057-61	RES-CHIP	2.2K	5%	1/10W
R3215	1-216-295-61	SHORT CHIP	0			R3274	1-216-069-61	RES-CHIP	6.8K	5%	1/10W
R3216	1-216-073-61	RES-CHIP	10G	5%	1/10W						
R3217	1-216-073-61	RES-CHIP	10G	5%	1/10W	R3277	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3218	1-216-065-61	RES-CHIP	4.7K	5%	1/10W	R3278	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
						R3279	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R3219	1-216-077-61	RES, CHIP	15K		(2012)	R3280	1-216-033-61	RES-CHIP	220	5%	1/10W
R3220	1-216-097-61	RES-CHIP	100K	5%	1/10W	R3281	1-216-033-61	RES-CHIP	220	5%	1/10W
R3221	1-216-073-61	RES-CHIP	10G	5%	1/10W						
R3222	1-216-073-61	RES-CHIP	10G	5%	1/10W	R3282	1-216-079-00	METAL CHIP	18K	5%	1/10W
R3223	1-216-065-61	RES-CHIP	4.7K	5%	1/10W	R3283	1-216-081-61	RES-CHIP	22K	5%	1/10W
						R3284	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3224	1-216-115-00	METAL CHIP	560K	5%	1/10W	R3285	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3225	1-216-073-61	RES-CHIP	10G	5%	1/10W	R3286	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3226	1-216-073-61	RES-CHIP	10G	5%	1/10W	R3287	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3227	1-216-129-61	METAL CHIP	2.2M	5%	1/10W	R3288	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3228	1-216-085-00	METAL CHIP	33K	5%	1/10W	R3289	1-216-073-61	RES-CHIP	10G	5%	1/10W
						R3290	1-216-081-61	RES-CHIP	22K	5%	1/10W
R3229	1-216-095-61	RES-CHIP	82K	5%	1/10W	R3291	1-216-079-00	METAL CHIP	18K	5%	1/10W
R3230	1-216-055-61	RES-CHIP	1.8K	5%	1/10W						
R3231	1-216-091-61	RES-CHIP	56K	5%	1/10W	R3294	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3232	1-216-089-61	RES, CHIP	47K		(2012)	R3295	1-216-065-61	RES-CHIP	4.7K	5%	1/10W
R3233	1-216-069-61	RES-CHIP	6.8K	5%	1/10W	R3296	1-216-065-61	RES-CHIP	4.7K	5%	1/10W
R3234	1-216-039-61	RES-CHIP	390	5%	1/10W	R3297	1-216-069-61	RES-CHIP	6.8K	5%	1/10W
R3235	1-216-101-61	RES-CHIP	150K	5%	1/10W	R3298	1-216-069-61	RES-CHIP	6.8K	5%	1/10W
R3236	1-216-113-61	RES-CHIP	470K	5%	1/10W						
R3237	1-216-065-61	RES-CHIP	4.7K	5%	1/10W	R3299	1-216-069-61	RES-CHIP	6.8K	5%	1/10W
R3238	1-216-073-61	RES-CHIP	10G	5%	1/10W	R6201	1-216-065-61	RES-CHIP	4.7K	5%	1/10W
						R6202	1-216-065-61	RES-CHIP	4.7K	5%	1/10W
R3239	1-216-073-61	RES-CHIP	10G	5%	1/10W	R6203	1-216-295-61	SHORT CHIP	0		
R3240	1-216-081-61	RES-CHIP	22K	5%	1/10W	R6209	1-216-049-61	RES-CHIP	1K	5%	1/10W
R3241	1-216-093-11	METAL CHIP	68K	5%	1/10W						
R3242	1-216-081-61	RES-CHIP	22K	5%	1/10W	R6213	1-216-073-61	RES-CHIP	10G	5%	1/10W
R3243	1-216-073-61	RES-CHIP	10G	5%	1/10W	R6214	1-216-073-61	RES-CHIP	10G	5%	1/10W
						R6219	1-216-089-61	RES, CHIP	47K		(2012)
R3244	1-216-073-61	RES-CHIP	10G	5%	1/10W	R6245	1-216-053-61	RES-CHIP	1.5K	5%	1/10W
R3245	1-216-097-61	RES-CHIP	100K	5%	1/10W	R6246	1-216-053-61	RES-CHIP	1.5K	5%	1/10W
R3246	1-216-065-61	RES-CHIP	4.7K	5%	1/10W						
R3247	1-216-101-61	RES-CHIP	150K	5%	1/10W	R6254	1-216-013-61	METAL CHIP	33	5%	1/10W
R3248	1-216-081-61	RES-CHIP	22K	5%	1/10W	R6255	1-216-308-61	METAL CHIP	4.7	5%	1/10W
						R6258	1-216-013-61	METAL CHIP	33	5%	1/10W
R3249	1-216-073-61	RES-CHIP	10G	5%	1/10W	R6259	1-216-308-61	METAL CHIP	4.7	5%	1/10W
R3250	1-216-049-61	RES-CHIP	1K	5%	1/10W	R6278	1-216-295-61	SHORT CHIP	0		
R3251	1-216-101-61	RES-CHIP	150K	5%	1/10W						
R3252	1-216-113-61	RES-CHIP	470K	5%	1/10W						
R3253	1-216-065-61	RES-CHIP	4.7K	5%	1/10W						
R3254	1-216-073-61	RES-CHIP	10G	5%	1/10W						
R3255	1-216-121-61	RES-CHIP	1M	5%	1/10W						
R3256	1-216-121-61	RES-CHIP	1M	5%	1/10W						
R3257	1-216-097-61	RES-CHIP	100K	5%	1/10W						
R3258	1-216-121-61	RES-CHIP	1M	5%	1/10W						
R3259	1-216-061-61	RES-CHIP	3.3G	5%	1/10W						
R3260	1-216-025-61	RES-CHIP	100	5%	1/10W						
R3261	1-216-025-61	RES-CHIP	100	5%	1/10W						

\*\*\*\*\*



The components identified by shading  
and mark  $\Delta$  are critical for safety.  
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	* A-1331-911-A	C BOARD MOUNTED *****				<IC>	
	4-382-854-11	SCREW (M3X10), P, SW (+)		IC701	8-759-561-28	IC STV5112	
				IC1800	8-759-822-38	IC LA6510	
		<CAPACITOR>				<JACK>	
C700	1-110-389-11	FILM MELF	0.1UF 5% 250V	J701	$\Delta$ 1-540-071-22	SOCKET, CRT	
C701	1-162-114-00	CERAMIC	0.0047UF 2KV			<COIL>	
C702	1-102-074-00	CERAMIC	0.001UF 10.00% 50V	L701	1-410-667-31	INDUCTOR	22UH
C707	1-137-399-11	MYLAR	0.1UF 5.00% 50V	L705	1-414-186-31	INDUCTOR	33UH
C708	1-102-228-00	CERAMIC	470PF 10.00% 500V	L706	1-414-186-31	INDUCTOR	33UH
C709	1-102-228-00	CERAMIC	470PF 10.00% 500V	L707	1-414-186-31	INDUCTOR	33UH
C710	1-102-960-00	CERAMIC	24PF 5.00% 50V			<TRANSISTOR>	
C711	1-102-852-91	CERAMIC	47PF 5.00% 50V	Q1800	8-729-139-98	TRANSISTOR 2SA1175TP-HFE	
C712	1-102-525-11	CERAMIC	68PF 5.00% 50V	Q1802	8-729-119-96	TRANSISTOR 2SC2785TP-HFE	
C713	1-102-228-00	CERAMIC	470PF 10.00% 500V			<RESISTOR>	
C716	1-128-526-11	ELECT	100UF 20.00% 25V	R700	1-249-393-11	CARBON	10 5% 1/4W
C717	1-107-651-11	ELECT	4.7UF 20.00% 250V	R701	1-249-496-11	CARBON	100K 5% 1/2W
C726	1-104-664-11	ELECT	47UF 20.00% 25V	R702	1-215-469-00	METAL	100K 1% 1/4W
C1800	1-126-964-11	ELECT	10UF 20.00% 50V	R703	1-215-414-00	METAL	510 1% 1/4W
C1803	1-126-964-11	ELECT	10UF 20.00% 50V	R704	1-215-414-00	METAL	510 1% 1/4W
C1804	1-126-964-11	ELECT	10UF 20.00% 50V	R705	1-240-297-91	METAL MELF	1.2K 5% 1/2W
C1809	1-126-942-61	ELECT	1000UF 20.00% 25V	R706	1-240-297-91	METAL MELF	1.2K 5% 1/2W
		<CONNECTOR>		R707	1-215-414-00	METAL	510 1% 1/4W
CN700	1-695-915-11	TAB (CONTACT)		R708	1-240-297-91	METAL MELF	1.2K 5% 1/2W
CN701	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P		R709	1-215-903-11	METAL OXIDE	68K 5% 2W
CN702	1-695-915-11	TAB (CONTACT)		R711	1-215-903-11	METAL OXIDE	68K 5% 2W
CN703	* 1-564-509-11	PLUG, CONNECTOR 6P		R712	1-215-903-11	METAL OXIDE	68K 5% 2W
CN704	1-695-915-11	TAB (CONTACT)		R713	1-215-467-00	METAL	82K 1% 1/4W
CN706	1-695-915-11	TAB (CONTACT)		R714	1-220-965-91	METAL CHIP	4.7K 5% 1/2W
CN1801	* 1-564-509-11	PLUG, CONNECTOR 6P		R715	1-220-954-91	METAL MELF	470 5% 1/2W
CN1802	* 1-564-506-11	PLUG, CONNECTOR 3P		R716	1-220-954-91	METAL MELF	470 5% 1/2W
		<DIODE>		R717	1-220-965-91	METAL CHIP	4.7K 5% 1/2W
D702	8-719-921-20	DIODE ISS119-25TD		R718	1-247-752-11	CARBON	1K 5% 1/2W
D703	8-719-921-20	DIODE ISS119-25TD		R719	1-220-965-91	METAL CHIP	4.7K 5% 1/2W
D704	8-719-921-20	DIODE ISS119-25TD		R722	1-247-752-11	CARBON	1K 5% 1/2W
D705	8-719-051-85	DIODE HSS83TD		R723	1-220-954-91	METAL MELF	470 5% 1/2W
D706	8-719-051-85	DIODE HSS83TD		R724	1-247-752-11	CARBON	1K 5% 1/2W
D707	8-719-051-85	DIODE HSS83TD		R730	1-216-392-11	METAL OXIDE	1.8 5% 3W
D708	8-719-921-20	DIODE ISS119-25TD		R734	1-247-739-11	CARBON	100 5% 1/2W
D709	8-719-921-20	DIODE ISS119-25TD		R744	1-215-415-00	METAL	560 1% 1/4W
D710	8-719-921-20	DIODE ISS119-25TD		R745	1-215-410-00	METAL	360 1% 1/4W
D711	8-719-110-23	DIODE RD11ES-T1B3		R1800	1-220-958-91	RES, METAL FILM 1K	
D720	8-719-921-20	DIODE ISS119-25TD		R1801	1-220-966-91	METAL CHIP	5.6K 5% 1/2W
D721	8-719-921-20	DIODE ISS119-25TD		R1802	1-249-382-11	CARBON	1.2 5% 1/4W
D722	8-719-921-20	DIODE ISS119-25TD		R1803	1-249-382-11	CARBON	1.2 5% 1/4W
D1803	8-719-921-20	DIODE ISS119-25TD		R1805	1-220-969-91	METAL CHIP	10K 5% 1/2W
D1804	8-719-921-20	DIODE ISS119-25TD		R1806	1-220-965-91	METAL CHIP	4.7K 5% 1/2W
D1808	8-719-908-03	DIODE GP08DPKG23		R1808	1-220-965-91	METAL CHIP	4.7K 5% 1/2W
				R1809	1-220-974-91	METAL CHIP	33K 5% 1/2W
				R1810	1-220-974-91	METAL CHIP	33K 5% 1/2W

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.



REF.NO.	PART NO.	DESCRIPTION	REMARK		
R1811	1-249-440-11	CARBON	82K	5%	1/4W
R1812	1-220-974-91	METAL CHIP	33K	5%	1/2W
R1821	1-249-440-11	CARBON	82K	5%	1/4W
R1822	1-220-974-91	METAL CHIP	33K	5%	1/2W
R1823	1-220-966-91	METAL CHIP	5.6K	5%	1/2W
R1824	1-220-974-91	METAL CHIP	33K	5%	1/2W
R1825	1-220-963-91	METAL MELF	3.3K	5%	1/2W
<VARIABLE RESISTOR>					
RV702	1-241-656-11	RES, ADJ, METAL FILM 110M			
RV1801	1-223-241-11	RES, ADJ, CARBON 47K			
<SPARK GAP>					
SG701	1-519-422-11	GAP, SPARK			
*****					
* A-1241-361-A		F BOARD MOUNTED	*****		
1-533-223-11		HOLDER, FUSE			
<CAPACITOR>					
C654	△ 1-117-703-11	CERAMIC	0.0047UF	99%	250V
C4601	△ 1-104-708-11	MYLAR	0.47UF	20.00%	250V
C4602	△ 1-109-835-11	MYLAR	0.68UF	20.00%	250V
<CONNECTOR>					
CN4601	* 1-580-843-11	PIN, CONNECTOR (POWER)			
CN4602	* 1-580-843-11	PIN, CONNECTOR (POWER)			
CN4603	1-695-915-11	TAB (CONTACT)			
<FUSE>					
F4601	△ 1-532-299-00	FUSE, TIME-LAG 5A/250V			
<RESISTOR>					
R4601	△ 1-202-719-00	SOLID	1M	10%	1/2W
<TRANSFORMER>					
T4601	1-431-536-11	TRANSFORMER, LINE FILTER			
T4602	1-431-182-11	TRANSFORMER, LINE FILTER			
<VARISTOR>					
VDR461	1-803-830-11	VARISTOR (ERZV14D621)			
*****					

REF.NO.	PART NO.	DESCRIPTION	REMARK		
	* A-1372-866-A	H3 BOARD MOUNTED *****			
	* 4-055-304-01	HOLDER, LED			
		<CAPACITOR>			
C3900	1-136-153-00	MYLAR	0.01UF	5.00%	50V
C3902	1-136-153-00	MYLAR	0.01UF	5.00%	50V
C3904	1-104-664-11	ELECT	47UF	20.00%	25V
C3905	1-125-805-91	ELECT	4.7UF	20.00%	50V
C3906	1-125-805-91	ELECT	4.7UF	20.00%	50V
C3910	1-104-664-11	ELECT	47UF	20.00%	16V
C3911	1-104-664-11	ELECT	47UF	20.00%	16V
C3912	1-102-114-00	CERAMIC	470PF	10.00%	50V
C3913	1-125-799-91	ELECT	1UF	20.00%	63V
C3914	1-126-965-11	ELECT	22UF	20.00%	50V
		<CONNECTOR>			
CN3601	* 1-580-844-11	PIN, CONNECTOR (POWER)			
CN3602	* 1-580-844-11	PIN, CONNECTOR (POWER)			
CN3603	1-695-915-11	TAB (CONTACT)			
CN3901	* 1-564-507-11	PLUG, CONNECTOR 4P			
CN3902	* 1-564-509-11	PLUG, CONNECTOR 6P			
CN3904	* 1-564-512-11	PLUG, CONNECTOR 9P			
CN3905	* 1-564-512-11	PLUG, CONNECTOR 9P			
		<DIODE>			
D3900	8-719-070-16	DIODE NNCD9.1A-T1			
D3901	8-719-070-16	DIODE NNCD9.1A-T1			
D3902	8-719-070-16	DIODE NNCD9.1A-T1			
D3905	8-719-070-16	DIODE NNCD9.1A-T1			
D3906	8-719-045-19	DIODE SPB-26MVWF			
D3907	8-719-070-16	DIODE NNCD9.1A-T1			
D3908	8-719-070-16	DIODE NNCD9.1A-T1			
		<IC>			
IC3901	8-742-014-21	HYB IC SBX1981-51(21)			
		<JACK>			
J3901	1-750-264-11	JACK			
J3902	1-784-646-11	TERMINAL, S			
J3903	1-770-329-11	JACK, PIN 3P			
		<COIL>			
L3901	1-414-183-41	INDUCTOR	10UH		
L3902	1-414-183-41	INDUCTOR	10UH		
		<TRANSISTOR>			
Q3901	8-729-030-02	TRANSISTOR DTC144ESA-TP			
Q3902	8-729-030-02	TRANSISTOR DTC144ESA-TP			



The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK		
<RESISTOR>					
R3900	1-220-952-91	METAL MELF	330	5%	1/2W
R3901	1-220-952-91	METAL MELF	330	5%	1/2W
R3902	1-247-804-11	CARBON	75	5%	1/4W
R3904	1-220-969-91	METAL CHIP	10K	5%	1/2W
R3905	1-220-969-91	METAL CHIP	10K	5%	1/2W
R3907	1-220-966-91	METAL CHIP	5.6K	5%	1/2W
R3908	1-220-954-91	METAL MELF	470	5%	1/2W
R3909	1-220-958-91	RES, METAL FILM 1K			
R3910	1-220-960-91	METAL MELF	1.8K	5%	1/2W
R3911	1-220-952-91	METAL MELF	330	5%	1/2W
R3912	1-220-963-91	METAL MELF	3.3K	5%	1/2W
R3913	1-220-969-91	METAL CHIP	10K	5%	1/2W
R3914	1-220-952-91	METAL MELF	330	5%	1/2W
R3915	1-220-969-91	METAL CHIP	10K	5%	1/2W
R3916	1-249-401-11	CARBON	47	5%	1/4W
R3917	1-247-804-11	CARBON	75	5%	1/4W
R3918	1-220-951-91	METAL	220	5%	1/2W
R3919	1-220-951-91	METAL	220	5%	1/2W
R3920	1-220-948-91	METAL	100	5%	1/2W
R3921	1-220-948-91	METAL	100	5%	1/2W
R3922	1-220-961-91	METAL CHIP	2.2K	5%	1/2W
R3923	1-220-951-91	METAL	220	5%	1/2W
R3924	1-247-804-11	CARBON	75	5%	1/4W
<SWITCH>					
S3601	△ 1-571-433-21	SWITCH, PUSH (AC POWER)			
S3902	1-692-431-21	SWITCH, TACTILE			
S3903	1-692-431-21	SWITCH, TACTILE			
S3904	1-692-431-21	SWITCH, TACTILE			
S3905	1-692-431-21	SWITCH, TACTILE			
S3906	1-692-431-21	SWITCH, TACTILE			
S3907	1-692-431-21	SWITCH, TACTILE			
S3908	1-692-431-21	SWITCH, TACTILE			
*****					
* A-1342-476-A		VM1 BOARD MOUNTED			
		*****			
4-382-854-11		SCREW (M3X10), P, SW (+)			
<CAPACITOR>					
C5902	1-104-661-91	ELECT	330UF	20.00%	16V
C5903	1-161-830-00	CERAMIC	0.0047UF		500V
C5905	1-126-925-11	ELECT	470UF	20.00%	10V
C5906	1-130-491-00	MYLAR	0.047UF	5.00%	50V
C5907	1-107-638-11	ELECT	33UF	20.00%	160V
C5908	1-106-383-00	MYLAR	0.047UF	10.00%	200V
C5909	1-126-933-11	ELECT	100UF	20.00%	16V
C5910	1-130-471-00	MYLAR	0.001UF	5.00%	50V
C5911	1-107-949-11	ELECT	2.2UF	20.00%	160V
C5912	1-104-999-11	MYLAR	0.1UF	10.00%	200V

REF.NO.	PART NO.	DESCRIPTION	REMARK
C5913	1-130-471-00	MYLAR 0.001UF 5.00% 50V	
C5914	1-126-933-11	ELECT 100UF 20.00% 16V	
C5916	1-130-491-00	MYLAR 0.047UF 5.00% 50V	
C5917	1-126-925-11	ELECT 470UF 20.00% 10V	
C5918	1-115-341-51	CERAMIC 120PF 10.00% 500V	
C5920	1-125-797-91	ELECT 10UF 20.00% 50V	
C5921	1-102-852-91	CERAMIC 47PF 5.00% 50V	
<CONNECTOR>			
CN5901*	1-564-510-11	PLUG, CONNECTOR 7P	
CN5904*	1-770-723-11	CONNECTOR, BOARD TO BOARD 8P	
<DIODE>			
D5901	8-719-921-20	DIODE 1SS119-25TD	
D5902	8-719-110-88	DIODE MTZJ-T-77-39	
D5903	8-719-921-20	DIODE 1SS119-25TD	
D5904	8-719-110-88	DIODE MTZJ-T-77-39	
D5905	8-719-921-20	DIODE 1SS119-25TD	
D5906	1-249-406-11	CARBON 120 5% 1/4W	
D5907	1-249-406-11	CARBON 120 5% 1/4W	
<COIL>			
L5901	1-414-187-11	INDUCTOR 47UH	
L5902	1-414-856-11	INDUCTOR 10UH	
<TRANSISTOR>			
Q5901	8-729-230-45	TRANSISTOR 2SC2458TP-YGR	
Q5902	8-729-809-26	TRANSISTOR 2SA1606-E	
Q5903	8-729-230-45	TRANSISTOR 2SC2458TP-YGR	
Q5904	8-729-139-98	TRANSISTOR 2SA1175TP-HFE	
Q5905	8-729-230-45	TRANSISTOR 2SC2458TP-YGR	
Q5906	8-729-809-29	TRANSISTOR 2SC4159-E	
Q5908	8-729-139-96	TRANSISTOR 2SC2785TP-HFE	
Q5909	8-729-139-96	TRANSISTOR 2SC2785TP-HFE	
<RESISTOR>			
R5901	1-220-951-91	METAL 220 5% 1/2W	
R5902	1-249-414-11	CARBON 560 5% 1/4W	
R5903	1-247-734-11	CARBON 39 5% 1/2W	
R5904	1-220-952-91	METAL MELF 330 5% 1/2W	
R5905	1-220-958-91	RES, METAL FILM 1K	
R5906	1-220-958-91	RES, METAL FILM 1K	
R5907	1-220-958-91	RES, METAL FILM 1K	
R5908	1-249-383-11	CARBON 1.5 5% 1/4W	
R5909	1-220-951-91	METAL 220 5% 1/2W	
R5910	1-220-946-81	METAL MELF 68 5% 1/2W	
R5911	1-249-439-11	CARBON 68K 5% 1/4W	
R5912	1-220-975-91	METAL MELF 47K 5% 1/2W	
R5914	1-220-946-81	METAL MELF 68 5% 1/2W	
R5915	1-220-969-91	METAL CHIP 10K 5% 1/2W	
R5916	1-220-959-91	METAL MELF 1.5K 5% 1/2W	
R5917	1-220-957-91	METAL MELF 820 5% 1/2W	
R5918	1-220-969-91	METAL CHIP 10K 5% 1/2W	

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.



REF.NO.	PART NO.	DESCRIPTION	REMARK
R5919	1-249-417-11	CARBON 1K	5% 1/4W
R5920	1-249-439-11	CARBON 68K	5% 1/4W
R5921	1-216-476-11	METAL OXIDE 180	5% 3W
R5922	1-220-955-91	METAL MELF 560	5% 1/2W
R5923	1-249-383-11	CARBON 1.5	5% 1/4W
R5925	1-249-400-11	CARBON 39	5% 1/4W
R5929	1-215-880-00	METAL OXIDE 10	5% 2W
R5930	1-220-954-91	METAL MELF 470	5% 1/2W
R5931	1-220-954-91	METAL MELF 470	5% 1/2W
R5932	1-220-954-91	METAL MELF 470	5% 1/2W
R5933	1-220-954-91	METAL MELF 470	5% 1/2W
R5934	1-220-970-91	METAL MELF 12K	5% 1/2W
R5935	1-220-969-91	METAL CHIP 10K	5% 1/2W

\*\*\*\*\*

#### MISCELLANEOUS

\*\*\*\*\*

$\triangle$ 1-403-619-81	COIL, DEMAGNETIZATION
$\triangle$ 1-451-475-11	DEFLECTION YOKE (Y25RSA)
1-452-094-00	CIRCULAR DISC MAGNET B
1-452-032-00	MAGNET, DISC
1-452-896-61	COIL, NA ROTATION (RT-200)
1-503-902-11	SPEAKER (15X6.5 CM)
1-529-190-11	SPEAKER (5CM)
$\triangle$ 1-574-062-61	CORD, POWER (WITH CONNECTOR) 2.5A/250V
$\triangle$ 8-733-250-05	PICTURE TUBE (A60LPN70X)
8-453-011-21	NA299-S

\*\*\*\*\*

REF.NO.	PART NO.	DESCRIPTION	REMARK
ACCESSORIES AND PACKING MATERIALS			
*****			
	3-701-910-00	SCREW, SPECIAL (DIA. 3.8X20)	
	3-865-956-11	MANUAL INSTRUCTION	
*	4-065-594-01	BAG, PROTECTION	
*	4-069-322-02	INDIVIDUAL CARTON	
*	4-069-323-01	CUSHION (UPPER)(ASSY)	
*	4-069-324-01	CUSHION (LOWER)(ASSY)	
	4-392-003-31	BAND, HOLD	
	4-392-004-21	CLIP	

\*\*\*\*\*

#### REMOTE COMMANDER

\*\*\*\*\*

1-418-038-11	REMOTE COMMANDER (RM-954)
9-933-895-01	BATTERY COVER, REMOTE COMMANDER

